

CLEARPATH-SC (IP66K/IP67) USER MANUAL

MODELS SCSK AND SCHP WITH IP66K/IP67 RATING IN NEMA 23 AND NEMA 34 FRAME SIZES VERSION 1.02 MARCH 18, 2024

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

TABLE OF CONTENTS			
TOP TIPS FOR CLEARPATH-SC USERS			
QUICK START GUIDE			
About ClearPath-SC7			
Who Should Use ClearPath-SC Motors?			
Please Read This Important Warning!			
Main System Components			
System Diagram8			
SC4-HUB			
DC Bus Power Supply8			
Logic Power Backup Supply (For use with POWER4-HUB-			
S)			
POWER4-HUB-S9			
POWER4-STRIP-S9			
Parts of a ClearPath-SC Motor10			
System Setup11			
1. Install ClearView Software			
2. Install the SC4-HUB "End-Of-Loop" Jumper			
3. Connect ClearPath-SC System Components			
4. Test DC Power Polarity			
5. Establish Communication (USB or RS-232 / Serial) 17			
Test Spin Your Motors Using ClearView			
Personal Safety Warnings 21			
Personal Safety Warnings			
Personal Safety Warnings			
Personal Safety Warnings			
Personal Safety Warnings 21 CE Compliance Warnings 21 General Disclaimer 22 INTRODUCTION 23			
Personal Safety Warnings 21 CE Compliance Warnings 21 General Disclaimer 22 INTRODUCTION 23 What is ClearPath-SC? 23			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25			
Personal Safety Warnings 21 CE Compliance Warnings 21 General Disclaimer 22 INTRODUCTION 23 What is ClearPath-SC? 23 Parts of a ClearPath-SC Motor 25 EXAMPLE CLEARPATH-SC SYSTEMS 26			
Personal Safety Warnings 21 CE Compliance Warnings 21 General Disclaimer 22 INTRODUCTION 23 What is ClearPath-SC? 23 Parts of a ClearPath-SC Motor 25 EXAMPLE CLEARPATH-SC SYSTEMS 26 Typical 4-Axis System (Single Port, 1 SC4-HUB) 26			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29Introduction29			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29Introduction29DC Bus Power Supply29			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29Introduction29DC Bus Power Supply29Logic Power Backup Supply (12-75VDC)29			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29Introduction29DC Bus Power Supply29Logic Power Backup Supply (12-75VDC)29DC Bus Power Supply: Teknic IPC-3 and IPC-5 75VDC.30			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29Introduction29DC Bus Power Supply29Logic Power Backup Supply (12-75VDC)29DC Bus Power Supply: Teknic IPC-3 and IPC-5 75VDC.3030Before Powering a ClearPath30			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29Introduction29DC Bus Power Supply29Logic Power Backup Supply (12-75VDC)29DC Bus Power Supply: Teknic IPC-3 and IPC-5 75VDC.3030Before Powering a ClearPath30Power Distribution Boards31			
Personal Safety Warnings21CE Compliance Warnings21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29Introduction29DC Bus Power Supply29Logic Power Backup Supply (12-75VDC)29DC Bus Power Supply: Teknic IPC-3 and IPC-5 75VDC.3030Power Distribution Boards31POWER4-HUB-S31			
Personal Safety Warnings.21CE Compliance Warnings.21General Disclaimer22INTRODUCTION23What is ClearPath-SC?23Parts of a ClearPath-SC Motor25EXAMPLE CLEARPATH-SC SYSTEMS.26Typical 4-Axis System (Single Port, 1 SC4-HUB)26Medium System (Single Port, 3 SC4-HUBs)27Large System (Multiple Ports and SC4-HUBs)28POWERING CLEARPATH-SC29Introduction29DC Bus Power Supply29Logic Power Backup Supply (12-75VDC)29DC Bus Power Supply: Teknic IPC-3 and IPC-5 75VDC.30Before Powering a ClearPath30Power Distribution Boards31POWER4-HUB-S31POWER4-HUB-S System Diagram32			

POWER4-STRIP-S34	ł
POWER4-STRIP-S: Things to Know	ł
Other Power Topics	3
On DC Bus Power Supplies	3
Compliance Notes	7
Power Supply Switching and Fusing	7
FAQ: "What size DC bus power supply should I use?" 37	7
COMMUNICATION AND I/O (THE SC4-HUB))
Introduction)
SC4-HUB Overview 39)
Parts of an SC4-HUB 40)
SC4-HUB Mounting 40	í Ì
SC4-HUB Operation (Connector by Connector) 40	í
24VDC Input / Pass-through Connectors	'n
USB Communication Connector (USB Comme) 40	Ś
RS-232 Communication Connector	, 1
ClearPath I/O Connector	L 1
Find of loop Headers	с 1
End-of-toop reducts	L)
Proba Control Connectors	5 1
Clobal Stan Connector	t 7
Giobal Stop Connector	(>
Salety Controls Concept Sketch	>
CONFIGURATION SOFTWARE (CLEARVIEW)49)
Minimum System Requirements49)
Installing ClearView Software49)
Establishing Communication With Your System50)
ClearView Software Tour50)
User Interface Overview50)
Manual Motor Controls	l
Dashboard52	2
Soft Scope53	3
ClearView Menus58	3
USING THE DIAGNOSTIC CHANNEL74	ł.
Terms Used in this Section74	ł
Connecting to the Diagnostic Channel	5
Changing Diagnostic Channel Access Modes	3
Troubleshooting Diagnostic Channel Connections79)
SOFTWARE LIBRARY AND SDK OVERVIEW80)
Introduction to the sFoundation Library)
sFoundation Class Hierarchy80)
INode (Node Level Classes)83	3
IPort (Port Level Classes)84	ł
SysManager (System Level Class)85	5
Software Development Kit (SDK)86	3
APPENDIX A: MOTOR LED BLINK CODES87	•
APPENDIX B: MECHANICAL REFERENCE	5
Dimensioned Drawings (links)	3
Motors	3

POWER4-HUB-S Expanded System Diagram......33

Boards	88
Accessories	88
Motor Mounting: Thermal Considerations	89
Connecting ClearPath-SC to a Mechanical System	90
Motor Connection: General Tips and Guidelines	90
Notes on Coupling Selection.	92
Installing Pulleys and pinions	93
About End-of-Travel Stops.	94
Hard Blocks	94
Elastomeric (rubber) Stops	94
Pneumatic (dashpots)	94
End Stops and Hard Stop Homing	94
Fan Mounting and Cooling.	95
APPENDIX C: CONNECTOR AND CABLE REFERENCE	96
Mating Connectors	
Cable Drawings and Pinouts (Links to Teknic.com)	
	00
ClearDath SC Mater: Common Specifications	90
SCA HUR Specifications	90
DOWEDA HUB S Specifications	100
DOWED4 STDID S Specifications	101
TOWER4-STRIT-S Specifications	101
APPENDIX E: GROUNDING AND SHIELDING	102
Protective Earth (PE) Connection	102
Grounding and Shielding	102
Power Returns	103
APPENDIX F: CIRCUIT SCHEMATICS	104
SC4-HUB Schematic (simplified)	104
APPENDIX G: WIRING THE INPUTS	106
Wiring a Mechanical Switch to an Input	106
Wiring a 24V NPN Sensor to an Input	106
Application Example: Wiring an Optical Sensor to an Inpu	at 107
APPENDIX H: MOTOR PART NUMBER KEY	108
	400
APPENDIX I: LOGIC POWER SUPPLY SIZING	109
APPENDIX J: HOW TO MAKE A 24V LOGIC SUPPLY	CABLE
	110

TOP TIPS FOR CLEARPATH-SC USERS

These tips apply to the fractional horsepower ClearPath-SC motors covered in this document.



- Don't operate Submerged. The sealed ClearPath is IP66K/IP67 rated but not designed to be operated submerged.
- ✓ Noise at First Enable? The brief buzzing sound you hear the first time your motor is enabled after power up is the motor initializing itself. This is normal (and necessary).
- ✓ Motor Killer! Reversing positive and negative DC bus power to your ClearPath motor will irreparably damage the motor. <u>More...</u>
- Cover Your Motor's USB-IR Port! To avoid communication issues due to a buildup of dust and debris over time, Teknic recommends covering your motor's USB-IR Port when not in use. Port covers are available at Teknic.com. Order part number CPM-COVER_USB_5P.
- ✓ USB Cables Matter. Use only Hi-Speed USB data cables to communicate with your ClearPath motor. "Charger only" cables won't work.
- Motor Blink Code? To understand what the various motor blink codes mean, 1) look up blink codes in the user manual (see <u>Appendix A</u>). 2) Establish USB connection to view exception/shutdown messages using the ClearView software.
- ✓ Auto-Tune Fully Loaded. Auto-Tune with your motor connected to the mechanics exactly as it will run during normal operation. The default motor tuning file that comes with your motor is designed for no-load operation only.
- ✓ Use different power supplies for main DC bus power versus low power logic (inputs and outputs). It may be tempting to use the same supply for 24VDC applications, but avoid doing so.

QUICK START GUIDE

This section was created to help users achieve the following objectives:

- Understand the ClearPath-SC system at a high level
- Connect the ClearPath-SC system components
- Install ClearView setup and configuration software
- Establish communication between a ClearPath-SC motor and PC
- Spin a ClearPath-SC motor using ClearView software

ABOUT CLEARPATH-SC

Thank you for choosing the ClearPath-SC all-in-one servo system with full software control. ClearPath-SC gives you the highest level of flexibility and control over your motors and machine application software, because you write it.

In the ClearPath-SC development model, Teknic provides you with the **sFoundation**, an advanced motion software library. ClearPath-SC is compatible with C++ for Windows/Linux and .NET languages (such as C#) for Windows. You write the machine application using development tools like Microsoft Visual Studio.

The included **ClearView configuration and setup software**, allows non-software personnel to tune, test, and exercise the servos right on the machine without coding a single line.

WHO SHOULD USE CLEARPATH-SC MOTORS?

ClearPath-SC users should be proficient in a programming language supported by ClearPath, such as C++ for Windows/Linux and .NET languages (such as C#) for Windows.

If you're not a strong coder, consider ClearPath-MC or ClearPath-SD motors for your project. The **ClearPath-MC family** features an assortment of preprogrammed operating modes, simplified digital controls, and *requires no coding*. The **ClearPath-SD family** accepts standard step and direction or quadrature AB control signals from any compatible controller, indexer, or similar device.

PLEASE READ THIS IMPORTANT WARNING!

Always use caution and common sense when handling motion control equipment. Even the smallest ClearPath motor is powerful enough to crush fingers, tear off a shirt sleeve, or pull out a patch of hair faster than the blink of an eye¹. These devices are extremely powerful and **dangerous if used carelessly**, so please read and follow all safety warnings in the ClearPath-SC User Manual before operating a ClearPath motor.

¹ The average duration for a single blink of the human eye is 100 to 400 milliseconds according to the *Harvard Database of Useful Biological Numbers*.

MAIN SYSTEM COMPONENTS

This section provides a brief overview and description of the main components of a ClearPath-SC system.





A 4-axis ClearPath-SC System

SC4-HUB

The SC4-HUB connects your computer and I/O devices to your ClearPath-SC motors. The SC4-HUB routes communication signals, passes sensor/switch inputs to the motors, includes 2 power-off brake outputs, and one Global Stop (e-stop) input. A maximum of 4 SC4-HUBs can be linked together to create systems of up to 16 axes per port, and up to 3 ports per computer, allowing you to create systems with as many as 48 motion axes.

DC BUS POWER SUPPLY

The DC Bus Power Supply provides main power to your ClearPath-SC motors. A Teknic IPC-5, 75VDC supply is shown above, but ClearPath-SC motors can be powered from other supplies in the 24–75VDC range.

LOGIC POWER BACKUP SUPPLY (FOR USE WITH POWER4-HUB-S)

When using the POWER4-HUB-S power distribution board, a Logic Power Backup Supply is required, the nominal range of which is 12VDC to 75VDC. The backup supply is meant to keep the ClearPath processor and associated electronics powered up in the event of loss of DC bus power. Motors cannot be operated (produce torque) on logic backup power.

Note: Many applications can and do share the same 24 VDC supply for the SC4-Hub, POWER4-HUB-S, and other 24 VDC devices in the systems.

POWER4-HUB-S

Distributes 24-75VDC bus power and 12-75VDC logic backup power to up to four ClearPath motors.

POWER4-STRIP-S

Distributes 24-75VDC bus power to up to four ClearPath motors.

Note: A logic power backup supply is not needed (nor is it compatible with) the POWER4-STRIP-S.

PARTS OF A CLEARPATH-SC MOTOR

Industry-leading, programmable, brushless servo motor with precision optical encoder, built in controller, trajectory generator, servo compensator, and torque drive.



Parts of a ClearPath-SC motor

DC Power Connector - This M12, 5-position, K-coded connector takes in DC bus power (24-75VDC) and logic backup power (12-75 VDC).

I/O Connector - This M12, 8-position, A-coded connector carries communication and input signals to ClearPath-SC.

USB-IR Port - Use this waterproof IR (infrared) communication port, in conjunction with the USB-IR converter, to connect ClearPath to a Windows PC running ClearView.

USB-IR Converter - (*Teknic part# CPMS-USB-IR*) This device translates USB signals to and from high speed infrared light pulses facilitating communication between a ClearPath motor and a PC running ClearView software. This device attaches magnetically to the ClearPath motor's USB-IR Port

USB-IR Port Cover - (*Teknic part# CPM-COVER-USB-5PC*) Prevents accumulation of dirt and/or particulate on the USB-IR port when it not in use. <u>Note: The USB-IR port is waterproof with or without this cover</u> <u>installed.</u> This item is sold in packs of 5.

Status LED - Tri-color LED Indicates the operational status of ClearPath device. See Appendix A for ClearPath LED codes.

Auxiliary PE (Protective Earth) Connection Point - Provides an alternative means of connecting the ClearPath motor to the machine's Protective Earth Terminal if the motor mount is not already bonded to PE. To use, connect a wire between this screw boss and a part of the machine frame/chassis that is bonded to machine PE.

SYSTEM SETUP

This section describes how to connect ClearPath-SC components, apply power, and establish communication with your PC. We'll show you how to run some basic test moves in the next section.

READ THIS BEFORE POWERING UP A CLEARPATH-SC SYSTEM

- **Do** secure your motors to a stable work surface.
- **Do** keep loose items such as cables, hair, and clothing away from motor shafts.
- **Do** observe static-safe handling practices when handling the SC4-HUB.
- **Do not** "hot swap" power connectors (i.e. don't connect or disconnect DC power connectors when the DC Bus Power Supply is powered up). This will cause electrical arcing, carbon scoring, and pitting of the terminals over time.
- **Do** install a protective (finger-safe) guard (or other physical barrier) around the motor shaft.

1. INSTALL CLEARVIEW SOFTWARE

- 1. Update your Windows installation. See note below for details.
- 2. Download the ClearView installer from Teknic's website: <u>https://www.teknic.com/downloads/</u>
- 3. Launch the ClearView Installer. Follow the on-screen prompts.

Important Software Installation Note

If your Windows installation is not up to date, ClearView may not run properly on your PC. During installation, the ClearView installer needs access to a few specific Windows system files. If these files are not found, Windows Update will attempt to install them. If Windows Update is disabled, and/or you have no internet connection, this may fail.

Teknic Drive Access Library
Can't load MNuserDriverXX.dll
ОК

If you install and attempt to run ClearView and see an error window like the one shown above, close ClearView and install this update: <u>https://support.microsoft.com/en-us/kb/2999226</u>. Then, re-launch ClearView.

2. INSTALL THE SC4-HUB "END-OF-LOOP" JUMPER

Place one (and only one) jumper block on the 2-pin header associated with the last motor connected to your SC4-HUB. Motors must be populated in order from CPO to CP3 (do not skip motor locations or the system will not communicate properly). Place the jumper on JO for a single motor, on J1 for two motors, and so forth. See the diagram below for details.



SC4-HUB jumper placement

Note: If you connect a second SC4-HUB, place one jumper at J5 on the first SC4-HUB. Then, on the second SC4-HUB, place one jumper at the last populated motor location.

3. CONNECT CLEARPATH-SC SYSTEM COMPONENTS

Before applying power, connect all ClearPath-SC components as shown in the hookup diagrams later in this section.

Note: *There are two different versions of the hookup diagram included in this section.* Please refer to the diagram that most closely matches your system.

24 VOLT SUPPLY FOR SC4-HUB

The SC4-HUB requires 24VDC power source. In a small ClearPath-SC system (4 axes or fewer) a 50-75 watt power supply is usually sufficient, but the minimum required power rating will depend on the power draw of all devices attached to the supply.

LOGIC POWER BACKUP SUPPLY (12-75VDC)

When using the POWER4-HUB-S power distribution board, a Logic Backup Power Supply is required. The range for this supply is 12VDC to 75VDC.

For help estimating how much power your logic power supply requires, see the Appendix I.

Tip: See Appendix J for instructions on how to make an inexpensive, nocrimp power cable for your low voltage logic supply.



SYSTEM HOOKUP DIAGRAM (WITH A POWER4-HUB-S)

Ref.	Mfg./Part Number	Description
А	Teknic/PC-SBR-72	Power cable. Molex Sabre 2-pin to Sabre 2-pin. 72"
В	Teknic/CPM-CABLE-M2P2P-120	2-pin Molex to 2-pin Molex multi-purpose cable. 10ft
С	Teknic/CPMS-CABLE-PWR-KM120	Power cable, M12 K-coded to Molex Mini-Fit Jr. 4, 10ft
D	Teknic/CPMS-CABLE-CTRL-AM120	Control cable M12, A-coded to Molex Mini-Fit Jr. 8, 10ft

ClearPath-SC Hookup Diagram (for systems with a POWER4-HUB-S)



SYSTEM HOOKUP DIAGRAM (WITH A POWER4-STRIP-S)

ClearPath-SC Hookup Diagram (for systems without a POWER4-STRIP-S)

4. TEST DC POWER POLARITY

Before applying power to your motor, please perform this quick test. It is well worth the few minutes it takes, and may save you significant amounts of time, money, and frustration.

IMPORTANT: Reversing DC Bus polarity or Logic Supply polarity *will* permanently damage your motor(s). This type of damage is not covered under warranty.

- 1. Start with the 5-position power connector disconnected from your ClearPath motor.
- 2. Power up your DC Bus Power Supply and Logic Power Backup Supply.
- 3. **Measure DC Bus Power Supply voltage and polarity.** With a multimeter, carefully measure the DC Bus Voltage from Bus Power+ to Bus Power-. (The actual voltage measured depends on your DC Bus Supply voltage.) **If you measure a negative value, the polarity is reversed.** Fix the problem and measure again.
- 4. **Measure Logic Power Backup Supply voltage and polarity.** With a DMM, carefully measure the Logic Power Backup Supply voltage between Logic Power+ and Logic Power. (The actual voltage measured depends on your Logic Power Backup Supply voltage.) **If you measure a negative value, the polarity is reversed.** Fix the problem and measure again.



Terminal Assignment Table			
Position	Wire Size	Color	Signal
1	16 AWG	Red	BUS Power +
2	16 AWG	Black	BUS Power -
3	22 AWG	Blue	Logic Power -
4	22 AWG	Orange	Logic Power +
5	N.C.	-	N.C.

Testing DC power polarity

5. ESTABLISH COMMUNICATION (USB OR RS-232 / SERIAL)

Next, you'll need to establish communication between your PC and the ClearPath-SC motors you want to control. There are two communication protocols available, USB or RS-232. Each is described in this section.

USB COMMUNICATION

- 1. Power up your ClearPath-SC system.
- 2. Connect USB cable from the SC4-HUB to your PC. This is a standard USB-A (male) to USB-B (male) cable.



USB-A (male) to USB-B (male)

- 3. Wait! Allow the drivers to auto-install. This may take a minute.
- 4. Launch the ClearView software.
- 5. ClearView will immediately attempt to auto-detect your motors. If all is well, you will see your motor(s) appear in the Motor List in ClearView.

	Motor List showing two motors connected to an SC Hub. Success!
IPM-SCSK-3421S-ELNA-1-5-D>> [modified]	
og Motion	COM29 - SC Hub (24V Power): ONLINE
3,000 Acceleration (RPM/s)	01: Unloaded <cpm-schp-3411p-elna-1-5-d></cpm-schp-3411p-elna-1-5-d>
erk Limiting ype: ⓒ RAS™ C g-Stop OFF Attack	
ime: 16 ms	
(cnts) Velocity (RPM) Dir (CCW) Step	Exceptions -

Two ClearPath-SC motors recognized in ClearView

6. If ClearView does not auto-detect your motors. Follow the steps described in *Setting the USB COM Port Manually*, below.

Setting the USB COM Port Manually

- 1. Open Device Manager (Windows systems).
- 2. Double-click "Ports (COM & LPT)".

3. Under Ports, locate "Teknic ClearPath 4-Axis Comm Hub (COM[n])". Take note of the value [n]—this is your COM port number.



- 4. In ClearView software go to File>Preferences.
- 5. Click the drop down menu in the section labeled "First".
- 6. Select the COM port [n] you identified above. Click "Done".

🔑 Applicatio	n Settings	×
SC-Hub COI	Il port(s):	Event Sounds Enabled:
First:	<no port=""></no>	Torque/Force Saturation
	<no port=""></no>	Voltage Saturation
		Limit Switch Struck
Second:	<no port=""></no>	Shutdown Occurs
		Online/Offline Change
Third:	<no port=""></no>	
	Auto-Detect Ports	Done Cancel

Select "Teknic ClearPath 4-axis Comm Hub" for First COM port

RS-232, SERIAL COMMUNICATION

Important: If you choose serial communication, your serial port must support a **minimum of 230k baud** to run ClearView software. If you do not know what speeds are supported by your serial port, check Windows Device Manager under Ports, or refer to your computer's documentation. Note: Applications running *without* ClearView will run properly down to 115k baud minimum.

If you want to use serial communication, and your serial ports aren't fast enough, you can find high speed serial port cards online from companies such as Axxon (softio.com) and Perle.

- 1. Power up your ClearPath-SC system.
- 2. Connect your serial communication cable (DB-9 to DB-9, straight-through) from the SC4-HUB to your PC.
- 3. Launch the ClearView application.
- 4. Click File>Preferences. A dialog box will pop up. In the section labeled "First", select the COM port number assigned to the serial port you are using.
- 5. Click "Done".

TEST SPIN YOUR MOTORS USING CLEARVIEW

Note: This section describes how to spin an unloaded motor (i.e. a motor with nothing attached to the shaft). Important: ClearPath-SC motors ship out pre-configured for *unloaded use only.* You must run the Auto-Tune application whenever you connect your motor to a different mechanical system.

Click and spin—no code required! Once your system is powered up and communicating, you can take your motors for a test spin using ClearView's Move Generator or Jog Motion controls. Here's how:

- 1. Select the motor you'd like to spin from the Motor List.
- 2. Set the Move Type: Back and Forth, Single, or Repeating.
- 3. Enter the Move Parameters: Distance, Velocity, Acceleration, and Dwell (Dwell is just the rest period between repeating moves).
- 4. Click Enable/Disable button once to enable the motor.
- 5. Click "Start Motion" (+ or -) button. Hit "+" to start motion in the counter clockwise direction; hit "-" to start motion in the clockwise direction
- 6. Single click the "Stop" button to end motion cycling. Double click the Stop button to stop motion immediately.

7.	Click	'E-Stop Al	l" or hit you	r Esc key to	o stop motion	immediately.
----	-------	------------	---------------	--------------	---------------	--------------

4 Enable/Disable Motor	e Parameters Aver Type	Active Motor
ClearView V1.0.26	[Axis 0]: configuration file <34115> [modified]	
File Edit Setup Acti Disable Motor Clear Exceptions E-Stop All (Esc) Torque Limit 100. % of max) © Override On	Image: Second	COM19 - SC Hub (ISB Power): OHLINE O0: JW_3411S O1: Unloaded <cpm-null-2321s-rqx-1-0-6></cpm-null-2321s-rqx-1-0-6>
Enabled	RMS Max: 5% Bus Volts Position (cnts) Velocity (kcnts/s) Input A In % 74.8 -525,383 0.0 ?	P
7 E-Stop	5 // START Motion plus(+) = CCW minus (-) = CW	

ClearView Main UI

-----End Quick Start Section-----

SAFETY WARNINGS

IMPORTANT: Read this manual before attempting to install, power up, or operate a ClearPath motor. Failure to understand and follow the safety information presented in this document could result in property damage, bodily injury, or worse.

PERSONAL SAFETY WARNINGS

- Do not wear loose clothing or unconfined long hair when using ClearPath-SC motors. Remove ties, rings, watches and other jewelry before operating an unguarded motor.
- Do not operate a ClearPath-SC motor if your alertness, cognitive function, or motor skills are impaired.
- Always handle, and carry a ClearPath-SC motor by the housing (don't carry it by the shaft or cable). Be aware that in certain scenarios ClearPath-SC is may spin as soon as main DC power is applied.
- Always understand how to use ClearPath-SC software controls and associated features before attempting to power, enable, or otherwise operate a ClearPath-SC motor.
- Install and test all emergency stop devices and controls before using ClearPath-SC.
- Before applying DC power, secure the ClearPath-SC motor to a stable, solid work surface and install a finger-safe guard or barrier between the user and the motor shaft.
- Provide appropriate space around the ClearPath-SC motor for ventilation and cable clearances.
- Do not allow cables or other loose items to drape over, or rest near the ClearPath-SC motor shaft.
- Never place fingers, hands, or other body parts on or near a powered ClearPath-SC motor.
- Thoroughly test all ClearPath-SC applications at low speed to ensure the motor, controls, and safety equipment operate as expected.

CE COMPLIANCE WARNINGS

- There are no user serviceable parts inside.
- Follow all instructions and use the product only as directed.
- Safety of any system incorporating this equipment is the responsibility of the system designers and builders.
- The machine designers need to recognize and incorporate required warning symbols, guards and shields for ClearPath-SC motors that are used in applications that can result in the external accessible parts of their machine exceeding a

temperature of 65 Celsius. This is required as a method to reduce burns. A tool shall be required to remove any guards and/or shields.

- ClearPath-SC motors require that a path exist between the motor chassis and the Protective Earth (PE) connection of the machine to which it is affixed. (Note: The PE connection is often satisfied by simply bolting the motor to the machine; however it is the users responsibility to verify the PE connection.) If an external grounding wire is required, use the same or larger wire gauge as used between the DC power supply and ClearPath Motor.
- Any maintenance or repair guide created by the user shall state that power shall be removed before the Protective Earth ground conductor is disconnected. When reconnecting power, the Protective Earth ground conductor shall be the first wire reconnected. Main power may be reconnected only after the Safety Ground connection is secure.

GENERAL DISCLAIMER

The User is responsible for determining the suitability of products for their different applications. The User must ensure that Teknic's products are installed and utilized in accordance with all local, state, federal and private governing bodies and meet all applicable health and safety standards.

Teknic has made all reasonable efforts to accurately present the information in the published documentation and shall not be responsible for any incorrect information which may result from oversights. Due to continuous product improvements, the product specifications as stated in the documentation are subject to change at any time and without notice. The User is responsible for consulting a representative of Teknic for detailed information and to determine any changes of information in the published documentation.

If Teknic's products are used in an application that is safety critical, the User must provide appropriate safety testing of the products, adequate safety devices, guarding, warning notices and machine-specific training to protect the operator from injury.

INTRODUCTION

WHAT IS CLEARPATH-SC?

ClearPath-SC is a multi-axis, servo-controlled motion system that allows you to connect up to 16 (or more) integrated servo motors into a tightly coordinated network. Inside each individual ClearPath-SC—in a package about the size of a normal motor—is a rare-earth brushless motor, a powerful servo drive, a motion trajectory generator, and a high-resolution optical encoder. ClearPath-SC's high performance, all-in-one convenience, and low cost makes it practical to use multi-axis servo control in any automated machinery application.



ClearPath-SC all-in-one servo motor

ClearPath-SC is a rugged, industrial-grade product. The motor subsystem is based on Teknic's <u>Hudson family</u> of brushless servo motors, with similar instrument grade bearings, stainless steel shaft, windings, rare earth magnets, and encoder technology. The servo drive electronics and motion control firmware employ the same state-of-the-art technology and advanced motion control algorithms as our high-end, non-integrated servo control products.



Example ClearPath-SC network. (DC bus wiring omitted for clarity.)

Tightly coordinate up to 16 or more motion axes per port (or more). ClearPath-SC's free C++ and .NET class libraries make it possible to write software for complex multi-axis applications. Simple applications can be written in a single execution thread, and, for more sophisticated systems, ClearPath-SC supports multi-threaded applications as well. Optional advanced firmware allows you to generate user-defined interrupts (attentions) for a variety of system events, allowing you to create highly responsive and deterministic multi-axis systems.

ClearPath-SC features a quick, automatic setup. Install the included ClearView software, connect ClearPath to your PC via USB or high-speed RS-232, and let it auto-tune itself to your mechanical system for optimum servo performance.

ClearView software allows you to get moving quickly. You can set many motor parameters, and exercise your mechanical system and electronics with just a few mouse clicks.

Safety and self-protection features are standard. ClearPath-SC will rapidly shut down if it becomes overloaded, overheated, detects a hard stop, or exceeds any of the safety or motion limits you specify.

Made in USA. Each ClearPath-SC motor is built and tested in our New York manufacturing facility, so you can be certain you're getting a high quality, fully tested motion control product right out of the box. And, Teknic backs up each ClearPath-SC motor with a three year warranty.



PARTS OF A CLEARPATH-SC MOTOR

ClearPath-SC Motor

DC Power Connector - This M12, 5-position, K-coded connector takes in DC bus power (24-75VDC) and logic backup power (12-75 VDC).

I/O Connector - This M12, 8-position, A-coded connector carries communication and input signals to ClearPath-SC.

USB-IR Port - Use this waterproof IR (infrared) communication port, in conjunction with the USB-IR converter, to connect ClearPath to a Windows PC running ClearView.

USB-IR Converter - *(Teknic part# CPMS-USB-IR)* This device translates USB signals to and from high speed infrared light pulses facilitating communication between a ClearPath motor and a PC running ClearView software. This device attaches magnetically to the ClearPath motor's USB-IR Port

USB-IR Port Cover - (*Teknic part# CPM-COVER-USB-5PC*) Prevents accumulation of dirt and/or particulate on the USB-IR port when it not in use. <u>Note: The USB-IR port is waterproof with or without this cover</u> <u>installed</u>. This item is sold in packs of 5.

Status LED - Tri-color LED Indicates the operational status of ClearPath device. See Appendix A for ClearPath LED codes.

Auxiliary PE (Protective Earth) Connection Point - Provides an alternative means of connecting the ClearPath motor to the machine's Protective Earth Terminal if the motor mount is not already bonded to PE. To use, connect a wire between this screw boss and a part of the machine frame/chassis that is bonded to machine PE.

EXAMPLE CLEARPATH-SC SYSTEMS

The ClearPath-SC system was created with both design flexibility and expandability in mind. This section shows a few examples of systems that can be built with ClearPath-SC components.

TYPICAL 4-AXIS SYSTEM (SINGLE PORT, 1 SC4-HUB)



⁴⁻axis ClearPath-SC system



MEDIUM SYSTEM (SINGLE PORT, 3 SC4-HUBS)

Medium system with multiple SC-Hubs connected to one computer port Active sensors powered through SC-Hub, e.g., proximity, optical, Hall-effect type, etc. 24V Power-off brake shown wired for axis 0

Π מממממממ Ē 민ᇢ Motion related τοφοφάρα sensors & signals (connected through to each motor) E 유민 🖵 הההההההה ī E-stop circuit Safety Controls 日 ηο 24 VDC -Safety

LARGE SYSTEM (MULTIPLE PORTS AND SC4-HUBS)

Power-off brake Controls USB מממק Guard interlock 3 switch and solenoid lock 24 VDC · RS-232 Windows Note: DC bus power (Linux) wiring omitted for clarity.

> Large system with multiple SC-Hubs connected to two ports Two area machine with guard lock under software control in one area 24V Power-off brake shown wired for one axis Mix of mechanical switches and active sensors powered from SC-Hub

POWERING CLEARPATH-SC

INTRODUCTION

ClearPath motors in this family require an external 24-75V **DC Bus Power Supply** such as the Teknic IPC-5 (75VDC), described later in this section and online <u>here</u>. **Note:** Properly specified third-party power supplies will also work with ClearPath motors.

ClearPath also supports an optional 12-75VDC **Logic Power Backup Supply** for applications where uninterrupted logic power is desired.

IMPORTANT: The motor cable connectors must be properly tightened to maintain IP67 (waterproof) rating. Failure to tighten these connectors may result in motor damage due to water ingress.

DC BUS POWER SUPPLY

The DC bus power supply provides main power to the ClearPath motor. The Teknic IPC-5 (75VDC) is one example of a ClearPath-compatible DC bus power supply.

The "Ideal" ClearPath DC Bus Power Supply

...is capable of delivering high peak current and handling back-EMF (reverse voltage generated by the spinning motor that "cancels" a portion of the incoming supply voltage). A power supply specifically designed for motor drive power—like Teknic's "Intelligent Power Center" supplies (IPC-3 and IPC-5)—will have these features, and are ideal for servo systems like ClearPath. "Bulk" linear power supplies—basically a transformer, rectifier, and large capacitor—can also work adequately. Normal switching-mode power supplies are generally not the best choice.

Important: Thoroughly test your ClearPath application with the intended power supply *under worst case, full load conditions* to ensure sufficient power capacity and adequate operating margin.

LOGIC POWER BACKUP SUPPLY (12-75VDC)

Users can opt to design in a Logic Power Backup Supply for applications that require uninterrupted power to the motor's processor and associated low power circuits.

Logic Power Backup Supply voltage range: 12VDC-75VDC

Logic Power Backup Supply current range: Application dependent

Important: The Logic Power Backup Supply <u>DOES NOT</u> supply power to the motor windings to achieve motion.

DC BUS POWER SUPPLY: TEKNIC IPC-3 AND IPC-5 75VDC

Teknic manufactures the IPC-3 and IPC-5 75VDC power supplies designed specifically for powering motor drives. These supplies effectively manage peak current demand, regenerated energy, and include many built-in protective features.



Teknic 75VDC IPC family power supplies

TEKNIC IPC-3

The IPC-3 open-frame power supply can typically power one to four ClearPath motors. The actual number of motors depends on the application. Please visit Teknic's website (<u>www.teknic.com</u>) for more information, features, and specifications.

TEKNIC IPC-5

The IPC-5 fully enclosed power supply can typically power two to six ClearPath motors. The actual number of motors depends on the torque, speed, and duty cycle required. Please visit Teknic's website (www.teknic.com) for more information, features, and specifications.

BEFORE POWERING A CLEARPATH

- Check for proper DC power polarity before connecting power to a ClearPath. Reversing DC power polarity will permanently damage the motor and void the warranty.
- Verify that the power supply is turned off and discharged before connecting the power cable to a ClearPath. Otherwise electrical arcing will damage the connectors over time.
- Never connect a NEMA 23 or NEMA-34 ClearPath motor directly to an AC outlet. This will damage the ClearPath motor and void the warranty.
- When a ClearPath motor is powered up, a startup routine energizes the motor for a few milliseconds. During this startup routine a small amount of motion may occur (1° typical).

POWER DISTRIBUTION BOARDS

ClearPath motors in this family require a power distribution board to supply DC bus voltage to the motor's power connector. Teknic offers two power board models: The **POWER4-HUB-S** and the **POWER4-STRIP-S**. The main difference between the two boards is that the POWER4-HUB-S supports a separate Logic Power Backup Supply; the POWER4-STRIP-S does not.

- **POWER4-HUB-S** Distributes 24-75VDC bus power <u>and</u> <u>(required) logic backup power from a separate supply</u> to up to four ClearPath motors per board. Logic backup power can range from as low as 12VDC to as much as 75VDC nominal.
- **POWER4-STRIP-S** Distributes 24-75VDC bus power to up to four ClearPath motors per board. <u>*The POWER4-STRIP-S does not support a separate logic power supply.*</u>



POWER4-HUB-S and POWER4-STRIP-S

POWER4-HUB-S

The **POWER4-HUB-S**:

- 1. Distributes DC bus power to up to four ClearPath motors.
- 2. Distributes logic backup power (required) to the ClearPath motor(s). Logic backup power will keep the motor's processor and associated electronics alive if DC bus power is lost. This means motor communication, encoder position, status monitoring, etc. will continue uninterrupted if bus power drops out.

Note: On its own, logic backup power will keep the motor's electronics alive, but cannot power the motor windings to produce torque at the motor shaft.

POWER4-HUB-S SYSTEM DIAGRAM



A single POWER4-HUB-S in a ClearPath system

POWER4-HUB-S: THINGS TO KNOW

- **IMPORTANT:** Never connect two IPC-3 or IPC-5 power supplies to a single POWER4-HUB-S. <u>The IPC power supplies</u> <u>are not designed to work in parallel or series configurations.</u>
- Logic backup power cannot be used to spin a motor, but it *will* maintain uninterrupted power to the motor electronics (encoder, DSP, communication, I/O, and associated circuits).
- **Do not "hot swap" DC power connectors.** Turn off DC Bus Power Supply before connecting a motor to the POWER4-HUB-S. *Connecting and disconnecting the motor from a live power supply will cause electrical arcing that will damage the connector terminals over time.*
- **Do not connect more than two POWER4-HUBs to a power supply.** Continuous and peak current usage must not exceed the power supply's specifications.
- Logic power requirement per motor:

2W (9-24VDC) 3W (>24VDC)



POWER4-HUB-S EXPANDED SYSTEM DIAGRAM



POWER4-STRIP-S

The **POWER4-STRIP-S** Distributes DC bus power to up to four ClearPath motors. This board serves as a basic "plug strip" for your ClearPath motors.

Note: The POWER4-STRIP-S board <u>does not</u> require a separate Logic Power Backup Supply.



POWER4-STRIP-S: THINGS TO KNOW

- **IMPORTANT:** Never connect two IPC-3 or IPC-5 power supplies to a single POWER4-STRIP-S. The IPC series power supplies are not designed to operate in parallel or series configurations.
- **Do not "hot swap" DC power connectors.** Turn off DC bus power supply before connecting a motor to the POWER4-STRIP-S. Connecting and disconnecting the motor from a live power supply will cause electrical arcing that will damage the connectors over time.

• **Do not connect more than two POWER4-STRIP-S boards to a power supply.** Continuous and peak current usage must not exceed the power supply's specifications.

OTHER POWER TOPICS

ON DC BUS POWER SUPPLIES

ClearPath motors can and do work with power supplies as low as 24 volts DC, provided that the power supply has sufficient voltage, current, and capacitance to meet your application's motor torque and speed requirements. This assumes that the motor has been properly sized for the application.

IMPORTANT: An underpowered supply can result in ClearPath performance limitations and problems including the following:

- **ClearPath is unable to complete the auto-tuning process.** The ClearPath auto-tuning feature uses aggressive moves to test the limits of each mechanical system. A weak power supply (i.e. one that can't handle the peak current demands required by ClearPath) may "droop" the supply below ClearPath's minimum operating voltage, about 21.5VDC. This can cause loss of communication and/or a safety shutdown. Needless to say, if Auto-Tune cannot run to completion, you probably have an underpowered supply.
- ClearPath completes the auto-tuning process but experiences certain warnings or shutdowns during programmed motion. If Auto-Tune runs to completion, but you experience torque saturation, voltage saturation, or both during regular machine operation, you may be exceeding the supply's voltage and/or current capability.

If you have an underpowered DC Bus Power Supply

If you suspect your power supply is underpowered, one of these solutions may work for you:

- Lower the commanded acceleration and/or velocity. Sometimes lowering commanded acceleration and/or velocity can reduce the burden on a weaker power supply enough to eliminate shutdowns caused by "power starvation".
- **Upgrade to a more powerful supply.** Look for a supply with higher voltage, higher peak and continuous current ratings, and a large capacitor bank.
Why you should avoid (most) switching power supplies

Switching power supplies are often not well suited to high power servo applications because they generally have the same peak *and* continuouscurrent ratings. This can lead the user to purchase a large but ultimately under-worked power supply just to meet peak current requirements.

In addition, **most switching supplies are not designed to handle the regenerated energy (back-EMF)** that a decelerating motor returns to the power supply. Without special provisions, regenerated energy can cause a switching supply to reset, power cycle, shut down, or even fail.

COMPLIANCE NOTES

- Any 3rd party (non-Teknic) power supply used with the POWER4-HUB-S or POWER-STRIP-S, should be current limited or fused to 25A or less using 25A, 300VDC (UL Listed) fuses.
- If UL compliance is a consideration, select a DC, UL Listed fuse.
- For those seeking a Class G fuse, the SC-25 from Eaton Cooper Bussmann, or OSLCO25 from Littelfuse is recommended. Fuse holders (also rated this way) include the HPS-FF and TCFH30N (from ECB/Littelfuse respectively).

POWER SUPPLY SWITCHING AND FUSING

POWER SUPPLY CONTROL SWITCH

The power supply for a ClearPath should not be switched on and off from the DC output side. Switching the DC output side, especially with inexpensive relays, will ultimately result in poor performance (drop outs) due to pitting, corrosion and contact welding. If a power switch is required, install it such that the supply is disconnected from the AC input side (see figure below).

POWER SUPPLY FUSING

If you require an external fuse on your power supply's DC output (to meet compliance standards for example) it should be installed in line with the positive leg of the DC output wiring Use a maximum 10A time delay fuse.

FAQ: "WHAT SIZE DC BUS POWER SUPPLY SHOULD I USE?"

Our engineers are asked this question all the time, and the short answer is: "it depends".

The exact power requirements for a given machine depend on several interrelated factors, including the number and type of motors and drives connected to the supply, the torque and speed requirement for each motor, environmental factors, and more.

Calculating the torque requirement for just a single axis can be challenging. This involves analysis of gearing, loading (both static and dynamic), reflected inertia, gravitational effects, friction, target accelerations, velocities, and machine throughput requirements. **Analyzing the machine as a system**, i.e. as a group of axes working together under all possible operational conditions adds even more complexity. At the systems level, factors such as axis duty cycle, effects of synchronous motion, and regenerated energy come into play.

In summary, selecting a power supply often begins with an educated guess followed by real-world testing. If you need to power several motors running at high speed and high torque, consider using a Teknic IPC-5, 75VDC power supply. Start with one supply but keep in mind that you can add another supply later if your application requires more power. If your machine is a single axis moving a light load at relatively low speed, a less powerful supply will likely suffice. Just be aware that testing may be required to find the right solution.

COMMUNICATION AND I/O (THE SC4-HUB)

INTRODUCTION

The SC4-HUB is the center of communication and I/O routing for all ClearPath-SC systems. The SC4-HUB links the application computer and I/O devices to your ClearPath-SC motors. Up to four SC4-HUBs can be linked together to create systems of 16 motors on a single USB or RS-232 port. ClearPath-SC systems can support up to a maximum of 48 axes².

IMPORTANT: The motor cable connectors must be properly tightened to maintain IP67 (waterproof) rating. Failure to tighten these connectors may result in motor damage due to water ingress.

SC4-HUB OVERVIEW

The SC4-HUB interfaces with:

- Application PC
- ClearPath-SC motors
- Input sensors and switches
- Global Stop input
- Brake Control outputs



SC4-HUB in a 4-axis ClearPath-SC system

² To support a 48 axis system, the application PC must have a minimum of three USB or RS-232 ports.

PARTS OF AN SC4-HUB



SC4-HUB with callouts

SC4-HUB MOUNTING

See <u>Appendix B</u>, *Mechanical Index*, for SC4-HUB mechanical/mounting dimensions.

SC4-HUB OPERATION (CONNECTOR BY CONNECTOR)

24VDC INPUT / PASS-THROUGH CONNECTORS

Connection point for the (required) 24VDC logic power supply. There are a total of two 2-pin Molex connectors wired in parallel; you can supply power to either one. The second connector may be used to daisy chain power to another SC4-HUB or another 24VDC device if desired.

USB COMMUNICATION CONNECTOR (USB COMMS)

This is a standard USB type B connector. Connect SC4-HUB to your PC using a readily available cable (USB-B to USB-A).

Important: Never connect a USB *and* **RS-232 connector to the same SC4-HUB.** This will cause communication errors.

RS-232 COMMUNICATION CONNECTOR

The SC4- HUB also has a high-speed RS-232 serial port built-in, so if you have an embedded host CPU without USB, you can use this instead. The DB-9 connectors also have the advantage that they can be positively locked by screwing them in.

This connector also serves as a data extension connector allowing users to chain multiple SC4-HUBs together regardless of whether communication into the first SC4-HUB is USB or RS-232.

CLEARPATH I/O CONNECTOR

This connector sends communication and input signals from the SC4-HUB to the ClearPath-SC motor. The required cable is M12 (A-coded) to Molex Mini-Fit Jr. 8, 10ft , Teknic PN: CPMS-CABLE-CTRL-AM120

END-OF-LOOP HEADERS

Place a jumper block on the 2-pin header associated with the last motor connected to your SC4-HUB. For example. if you are connecting just one motor to the SC4-HUB, place the jumper on J0. For two motors, place the jumper on J1. If you plan to connect a second SC4-HUB (for systems with five or more motors) place the jumper at J5, then on the second SC4-HUB place a jumper on the appropriate header.

INPUT A AND B CONNECTORS

Each ClearPath I/O connector on the SC4-HUB has two inputs associated with it: *Input A and Input B*. Each input has its own 4-pin Molex connector as shown below.

The inputs are designed for use with 24VDC, ³ NPN type sensors or mechanical switches. The inputs are optically isolated, digitally filtered, current limited, and reverse polarity protected for robust, long-term performance. For more on how the inputs work, see the input circuit schematic (below) and Appendix G, *Wiring Inputs A and B*.



ClearPath-SC Input A and B Connectors

Maximum Input Cable Length

Cables used for SC inputs can be a maximum of 100 feet (30 m) long. However, longer cable runs may be possible if the cable stock is of high quality, low capacitance, twisted pair construction. Contact Teknic if you need input cables longer than 100 feet (30 m).

³ ClearPath -SC motors can accept inputs from devices with logic high ranging from 5-24VDC, but the SC Hub, by default, accepts 24VDC NPN type sensors or simple mechanical switches.



Schematic snippet: Input A and B

MINIMUM CURRENT REQUIREMENT

Input devices wired to ClearPath-SC inputs must be able to source/sink a minimum of 12mA.

Engineer's Note: In all ClearPath-SC motors, the logic-level signals are electrically isolated from the DC power input and motor output circuits, as well as from the motor case to ensures that control signals are not compromised by induced currents from the motor, power supply, or PWM return path.

BRAKE CONTROL CONNECTORS

These two, 2-pin Molex Minifit Jr. connectors allow you to control "power-off" style 24VDC inline brakes. They can also be used as general purpose outputs (GPOs) to control any 24VDC device through your application code.



Brake Control Connectors

BRAKE BASICS

- Only two Brake Control outputs can be used *per port*. This means, if 4 SC4-HUBs are chained together and connected to a single USB or serial port, only the two brake outputs on the first SC4-HUB in the chain would be useable.
- Brake Control 0 and Brake Control 1 are linked to Axis 0 and Axis 1 respectively. This is a fixed, relationship.
- The Brake Control circuit was designed for use with 24VDC "power-off" type brakes that draw 500mA or less.
- Brakes will not release (allow motion) unless communication with a motor has been established.
- Brakes automatically engage (disallow motion) if communication with the Application PC is interrupted.

Engineer's Safety/Compliance Note: Depending on your machine application and safety compliance requirements (i.e. ISO 13849) external safety controls may be required when using this feature. The section "Safety Controls Concept Sketch" includes a high level safety system diagram for general reference.

BRAKE CONTROL CIRCUIT

The figure below shows a schematic fragment of one of the Brake Control circuits (Brake Control 0). See the Schematics appendix for complete SC4-HUB circuit drawings.



Schematic: Brake Control 0

CAUTION: BRAKE CONTROL SAFETY NOTE

In order to function, the brake control circuitry, by design, is accessible to the host operating system (e.g., Windows). Because of this, however, when your ClearPath-SC application code does not have control of the host's communication port (USB or serial), it is possible for the operating system to inadvertently release the brake. This can happen, for example, if the operating system scans its connected hardware (like during a port "auto-discover" function).

To eliminate inadvertent motion, your SC application should position all brake-fitted axes to their lowest potential energy state before exiting (i.e. before releasing the port back to the operating system). For example, position a vertical axis at the bottom of its motion range if it could otherwise fall when acted upon by gravity.

Whenever movement of any brake-fitted axis could result in a safety hazard, the brake outputs should be wired in series with an interlock switch circuit to all guard mechanisms preventing unsafe operator access, whether directly or through a safety controller. **Note: any safety circuit of this type must go open circuit when unsafe access is attempted to assure brake actuation.**

SETTING BRAKE CONTROL BEHAVIOR IN CLEARVIEW

The Brake Control outputs can be toggled manually or set to automatic operation through the ClearView Actions menu: *Actions>Brake 0*, or *Actions>Brake 1*.

Additional notes:

• Only two brake control outputs can be used per port connection; i.e. if four SC4-HUBs are chained together, only the two brake control outputs on the first SC4-HUB will be controllable.

GLOBAL STOP CONNECTOR

IMPORTANT: This is a software-based node stop control only. It is not a critical safety E-stop system.

This 2-pin Molex Minifit Jr. connector allows you to connect the E-Stop output from a safety controller to your SC4-HUB.

Engineer's Safety/Compliance Note: Depending on your machine application and safety compliance requirements (i.e. ISO 13849) external safety controls may be required when using this feature. The section "Safety Controls Concept Sketch" includes a high level safety system diagram for general reference.



Schematic snippet: Global Stop Input

SAFETY CONTROLS CONCEPT SKETCH

The generic safety system sketch below is intended to provide a general idea as to how an engineer might approach the design of safety controls for a ClearPath-SC system⁴.



Safety system high level design concept

⁴ The figure above does not represent an existing, real world safety system for which parts have been sourced, prototypes built/tested, or formal documentation generated. As such, Teknic makes no representations as to the accuracy of this content, or suitability of this conceptual design for any purpose.

CONFIGURATION SOFTWARE (CLEARVIEW)

ClearView software provides a suite of powerful configuration, analysis, and diagnostic tools to speed machine *and* software development. These tools—the Soft Scope in particular—make it easy to capture valuable motion performance data whether you're in the lab, on the production floor, or in the field.

This section includes the following topics:

- PC system requirements
- Installing ClearView software
- Tour of ClearView software

MINIMUM SYSTEM REQUIREMENTS

Operating System: Processor: Memory: HD Free Space: Monitor: Other: Windows 7, 8.1, 10 1.5 GHz or faster 1 GB RAM 1 GB 1280 x 1024 pixels or higher Sound card with speakers (optional)

INSTALLING CLEARVIEW SOFTWARE

- **Run Windows Update.** See note *Windows Update and ClearView* below.
- Download the ClearView installer from <u>https://www.teknic.com/downloads/</u>.
- Launch the ClearView installer. Follow on-screen prompts to complete installation.

Windows Update and ClearView Installation

If your Windows installation is not up to date, ClearView may not run properly. During installation, the ClearView installer needs access to a few specific Windows system files. If these files are not found, Windows Update will attempt to install them. If Windows Update is disabled, and/or you have no internet connection, this may fail.

ſ	Teknic Drive Access Library
	Can't load MNuserDriverXX.dll
	ОК

If you install and attempt to run ClearView and see an error window like the one shown above, close ClearView and install this update: https://support.microsoft.com/en-us/kb/2999226. Then, re-launch ClearView. See ClearPath-SC Quick Start Guide.

CLEARVIEW SOFTWARE TOUR

USER INTERFACE OVERVIEW

The ClearView UI is presented in four parts: the *Menu, Manual Controls, Dashboard*, and *Soft Scope*. Each of these parts is discussed in detail in this section.



ClearView UI Overview

MANUAL MOTOR CONTROLS

The Manual Motor Controls comprise a set of tools designed to help you test and exercise your ClearPath-SC motors *without writing a single line of code*. Manual Controls give you the ability to:

- Enable, disable, and E-stop motors
- Manually jog motors
- Run profiled moves (reciprocating, single, or unidirectional repeating)
- Modify the torque limit setting, and more



Manual Controls section of ClearView UI

DASHBOARD

The Dashboard features virtual indicators and readouts for motor status, encoder position, motor velocity, bus voltage, input states, exception messages, and more.



Dashboard section of ClearView UI

SOFT SCOPE

OVERVIEW

The ClearView Soft Scope takes real-time streaming data from your ClearPath-SC motor and plots it on a scope display in an intuitive, easy-tointerpret manner. The Soft Scope can display your motor's *actual torque output, position error, commanded velocity, acceleration,* and more. This is a great tool for engineers, technicians, or maintenance professionals tasked with the analysis or troubleshooting of motors, motion, and mechanical performance.

The Soft Scope consists of three main sections: the **Scope Display (1)**, **Strip Chart (2)**, and **Scope Controls (3)**. Together, these components emulate much of the functionality of a digital storage oscilloscope and data analyzer.



ClearView Soft Scope

SOFT SCOPE FEATURES

- 13 scope variables that can be plotted in real time
- Four trigger modes
- Adjustable timebase, range, and trigger position
- Simultaneously display two stored traces + one live trace
- 13 trigger presets (Example: trigger at end of settled move)
- Interactive cursors for precise timing and amplitude measurements
- Strip Charts for a consolidated view of motor status, input states, and move timing

SCOPE DISPLAY AND SCOPE CONTROLS

The ClearView Scope display is modeled after a typical hardware oscilloscope. It has 10 major vertical divisions (the time axis), and 8 major horizontal divisions (the amplitude axis).



ClearView Soft Scope

1 The Scope Variable drop down menu lets you select any of 13 ClearPath-SC motion control variables to display. These variables are Tracking Error, Commanded Velocity, Actual Torque, Actual Velocity, Velocity Error, Commanded Torque, SGN (sign of velocity), Measured Position, Commanded Jerk, Commanded Acceleration, Max Phase Voltage, Torque Error (peak), and Bus Voltage.

2 The Timebase field lets you adjust the scale of the time axis (think X-axis) in units of mS/division. This allows you to control how a waveform fits horizontally on the Scope Display.

Example: With the Timebase set to 10mS per division (as in the figure above) the full horizontal range of the Scope Display is 100mS (10 divisions x 10mS/division).

3 The Range field lets you adjust the scale of the amplitude axis (think Y-axis). This allows you to control how a waveform fits vertically on the Scope Display.

Example: In the figure above, the green "live" trace represents the motor's tracking error (i.e. how close is the actual motor position to the commanded position). The Range is set to 100 counts.

To interpret the displayed information, you only need to understand a few things: 1) the center horizontal line represents 0 counts of tracking error (perfect tracking), 2) the top of the Scope Display represents +100 counts of tracking error, and 3) the bottom of the scope display represents -100 counts of tracking error. The +/- distinction is necessary because the actual motor position can lead *or* lag the commanded position. By doing a little math you will find that each major horizontal division represents 25 counts of error.

4 Cursor controls display time and amplitude measurements of the live trace. Note: the time readout for the cursors is referenced to the Trigger Point (that's where t = 0). Amplitude is measured relative to the horizontal center line. The delta (Δ) function automatically displays the difference between the two cursor values. Click and drag cursors to reposition them. Click the *Show* button to make cursors appear if they are hidden.

5 Trace Storage controls let you save and display two traces on the scope display. Just capture a waveform and click either the STO 0 or STO 1 button (Storage 0 and Storage 1). The selected trace is then stored and displayed in either pink (STO 0) or blue (STO 1). Hide or show either stored trace by clicking its respective On/Off button.

6 The Trigger Source ("Trigger On") menu lets you choose what conditions must be met before scope data collection begins (is triggered). The following Trigger Source options are available:

MSP Scope will:

Start of Positive Command	Trigger at the start of any positive move; useful for tuning.
Start of Negative Command	Trigger at the start of any negative move; useful for tuning.
Start of Any Command	Trigger at the start of any move (positive or negative); useful for assessing bi-directional tuning performance.
End of Positive Command	Trigger at the end of any positive move; useful for assessing settling performance.
End of Negative Command	Trigger at the end of any negative move; useful for assessing settling performance.
End of Any Command	Trigger at the end of any move (positive or negative); useful for assessing bi-directional settling.
End of Positive Settled Move	Trigger at the end of any positive move after Move Done criteria are met; useful for assessing settling performance.
End of Negative Settled Move	Trigger at the end of any negative move after Move Done criteria are met; useful for assessing settling performance.
End of Any Settled Move	Trigger at the end of any move (positive or negative) after Move Done criteria are met; useful for assessing settling performance.
Voltage/Torque/Speed Limit	Trigger on first occurance of saturation (voltage <i>or</i> torque) or upon speed limiting; useful for determining which moves (or segments of moves) exceed these thresholds.
Drive Shutdown or Exception	Trigger on the assertion of an exception or safety shutdown; useful for determining the operational status at the time of a fault.
Rising Slope	Trigger on the rising edge of the active waveform.
Falling Slope	Trigger on the falling edge of the active waveform.

If Trigger Source is set to:

7 Trigger Mode settings allow you to select exactly when data acquisition begins and ends. These controls are similar to the trigger modes found on typical digital storage oscilloscopes.

- **Normal** Causes scope data collection to begin whenever a valid trigger source is detected.
- **Single** Works the same as *Normal* mode, except it captures only a single data set when a valid trigger source is detected. After the single sweep capture, data collection automatically stops.
- **Auto** This is the rolling, "always on" setting. Data is continuously collected, refreshed, and displayed regardless of the trigger source settings.
- **Force** Forces the scope to trigger immediately, regardless of trigger source setting. As with Single mode, only one data set is collected and displayed; then data collection stops.
- **Stop** Causes scope data collection to stop. It does *not* clear previously captured data from the scope display.

8 Trigger Position buttons allow you to position the trigger point on the left (10% position, as shown in the previous figure), middle (50% position), or on the right side (90% position) of the scope display grid. This is useful for viewing events on the scope that occur before, during, or after the trigger point.

9 The Trigger Level lets you select the amplitude at which the scope will trigger.

Note: Trigger Level can only be used when Trigger Source is set to "Rising Slope" or "Falling Slope".

Tip: Use Trigger Level when the Trigger Mode is set to "Normal" or "Single" to facilitate waveform display at a fixed trigger point.

10 The Scope Filter "cleans up" or smoothes the appearance of the displayed trace by removing higher frequency data content. This has an averaging effect on the displayed waveform that can help mitigate the effect of noise (or just remove visual clutter) on the displayed signal.



Effect of Scope Filter on trace display

Note: The Scope Filter has no effect on motor performance. *It changes only how scope data is displayed.*

Note: Higher filter setting may filter out meaningful data points from the display (peaks in particular).

Tip: In most cases Scope Filter can be left "OFF" or at the lowest setting.

STRIP CHART

The Strip Chart provides a visual overview of your motor status, input states, and motion performance. A quick look at the strip chart can tell you if the motor is enabled, shut down, hit a limit, whether the inputs are asserted or not. And, because the Strip Chart display is always in sync with the main scope trace, there's no extra setup required.



ClearView Strip Chart display

Strip Chart Legend

This key explains the strip chart trace colors and symbols. Click the isymbol to the left of the strip chart display to open.

CLEARVIEW MENUS

This section covers the ClearView menu bar and menu items.



ClearView Menu Bar

FILE MENU

ile	Edit	Setup	Action	Details	Access [Full]	About	
ζ ^{Γο}	ad Co	nfigurat	ion		Ctrl+O	-	
Sa	ive Co	nfigurat	ion		Ctrl+S		-
Re	eset C	onfig File	e to Fact	ory Defau	ults		
Ex	(port)	ML File.			Ctrl+L		5.0
Pr	eferer	nces					
Fir	mwar	e Updati	e				
Ev	at				Ctrl+Q	°M/s)	Jer
				000	Descall 4		Typ

ClearView File Menu

Load Configuration (Ctrl+O)

Allows you to load motor configuration files to your ClearPath-SC motors. The file extension is mtr.

Save Configuration (Ctrl+S)

Allows you to save your ClearPath-SC configuration settings to your PC as a .mtr file.

Reset Config File to Factory Defaults

Restores ClearPath-SC to its factory default configuration (i.e., the way it was configured when you received it). All existing settings will be overwritten. Save your current configuration as a .mtr file (described above) if you think you'll need to use it some other time.



Export XML File

Beta feature for Teknic internal use at this time.

Preferences

Opens a dialog that lets you manage COM port settings and event sounds in ClearView.

Po Cli to po do	rt Assig ck drop manuall rts if aut es not d	nments down menu y select o-detectior o so.	u n		Eve Jnc ndi Click orev	nt So heck vidua k spe view	bun box al ev ake evei	ds Contr kes to dis vent sour r icon to nt sound	r ol sable nds. Is.		
🔑 Application	n Settings										×
SC-Hub COM	1 port(s):				_	Eve	nt So	unds Enabl	ed:		
First:	Teknic Cle	arPath 4-axis (Comm Hub (C	OM23) 🔻				Torque/Fo	rce Saturation		
	,					(ا		Voltage S	aturation		
					•			Limit Swit	ch Struck		
Second:	<no port=""></no>			-		(ک		Shutdown	Occurs		
	·					1 00	- [7]	Online/Of	fline Change		
Third:	<no port=""></no>			-							
			Auto-Det	tect Ports					<u>D</u> one	Cano	el
L											
			Auto-D Click to	etect Po	earV	/iew	ted				
			ClearPa	th -SC de	evic	es.					

Preferences

Firmware Update

Allows for field update of ClearPath firmware.

EDIT MENU

Edit Setup	Action	Details	Acce
çıy		Ctrl+	+X
Сору		Ctrl+	ŀС
Paste		Ctrl+	+V
Motor ID			
Zero Positio	on Ctrl	+0	
Reset RMS	Peak		

ClearView Edit Menu

Cut, Copy, Paste

These are just standard Windows commands and keyboard shortcuts.

Select this menu item to open a window as shown below. There you can enter a customized name for your motor. There's also space to enter additional notes on the system. Text entered will remain in your motor's non-volatile memory even when all power is removed.

Motor Name	
This is a user-defined name for the is shown in the main MSP title bar.	motor (up to 25 characters) that
For example, "Titan x-axis".	
JW X Axis (3411S)	
Mechanical System Description —	
This description identifies what wa was auto-tuned. This allows you to been changed since the auto-tunin	s connected to the motor when it recognize if the mechanics have g procedure.
For example, "Ballscrew: 1m long, 15m Bearing wiper removed. Medium cable t	n dia., 5mm pitch. Load mass, 10kg. rack."
Available characters = 95	
Enter useful information here	
Verify Tuning Upon Connection	
foring running open connection	
By default, upon USB connection, (to start the auto-tuning process if the since the motor was last auto-tune appearing for this serial number m	ClearPath MSP will remind you he mechanics have changed d. To prevent this reminder from lotor, check the box below.
By default, upon USB connection, to start the auto-tuning process if th since the motor was last auto-tune appearing for this serial number m will remember to re-tune if the Do not ask again for this motor.	ClearPath MSP will remind you he mechanics have changed d. To prevent this reminder from hotor, check the box below. mechanical system changes.

ClearView Motor ID Window

Zero Position (Ctrl+0) <--- that's a zero

Click or use keyboard shortcut Ctrl-0 to zero the Position Counter on the ClearView Dashboard.

Tip: You can also zero the Position Counter by simply double-clicking it directly on the Dashboard.

Reset RMS Peak

Click to set value of *RMS Max* to the current RMS value. (This applies to the RMS Meter in the Dashboard section of ClearView.)

SETUP MENU

The Setup Menu provides a simple, no code required, way to manage frequently used motion control actions and events such as input behaviors, homing, torque limiting, software limits, Auto-tune, and more.

Setup	Action	Details	Acce					
Inpu	it Actions							
Torg	que Limitir	ng						
Hom	ing Setu	D						
Soft	Software Limit Setup							
Auto	o-tune							
Fine	Tuning							
Ope	rating Mo	ode						
Units	s		•					

Input Actions

The upper section of the window lets you select one or more actions to execute when a state change is detected at Input A or B.

The lower section of the window lets you specify precisely when to trigger an encoder position capture.

Note: The Position Capture feature is always enabled; it can be simply disregarded if not used.

Note: Input A captures encoder positions at 0.1 microsecond resolution; Input B captures at 300 microsecond resolution. These values are not adjustable.

Input Actions		Jse upper section to specify actions to be executed upon nput state change.
Input A	Input B	Action
		Stop motor when Input turns off Setup
		Torque Limit Setup
		Start a triggered-type move when input turns on
		Stop motion in set-up direction (like a limit switch)
- Capture P	/hen	
Input A	Turns on	0.1µs resolution Note: Position Capture is always enabled,
Input B	Turns on	regardless of other Input Action settings.
	Turns on Turns off	Use lower section to specify the

Input Actions Setup

61

This menu item brings up a selection of conditional torque limiting options (see figure below).

The user-defined torque	e limit values will b	e used when any of the below conditions are true.
Limit Torque?	Limit	Limit Torque When
Don't Limit 💌		torque when Move Done is true
Don't Limit 💌	V	torque when 0 counts after move start occurs ?
Don't Limit 💌	y	torque when 0 counts before move end occurs ?
Don't Limit 💌	Y	torque when Absolute position > v
	CCW (+) 🔻	torque when Input A Turns On
Don't Limit 💌		torque when Input B
- Torque Limit Value	s	
CW (-) Torque Lim	iting	CCW () Torque Limiting
Torque (% of max) 5.	Torque (% of max) 8.
Transition Time (m	ns) 200	Transition Time (ms) 120

Torque Limiting Setup

Example: the above conditional statement (indicated with a red star) reads: *Limit CCW(+) torque when Input A turns on.*

The "long form" translation is this: *When Input A turns on, institute a torque limit in the CCW (+) direction of 8% of the motor's maximum peak torque capability. Transition from the current torque limit to the 8% torque limit over 120 mS from the time Input A turns on.*

Homing Setup

The Homing Setup dialog lets you quickly set up frequently used homing parameters without the need to code them into your application software.

Homing Move Parameters —			
Max Velocity During Home Move	s (RPM)	40.0	
Max Accel. During Home Moves	(RPM/s)	500	
loming Target			
Change of Input			
O A Input Turns On	B Input Tu	irns On	
C A Input Turns Off	O B Input Tu	urns Off	
Hard Stop			N
Homing Torque Limit (% of	max) 5.		43
Offset Move			
Distance From Homing Targ	et (onts) 1,5	00 C	CW (+)
Note: When homing is comp motor position will be = 0.	lete (after the of	ffset move), the	Э
Homing Offeet Direction			
Reverse of Home	🔿 Same a	as Home	
	г	orl	Cancel

Homing Setup

Software Limit Setup

This feature lets you define travel limits in terms of encoder position, with no sensors or switches required.

To use this feature, Check *Enable Software Limits* and set the two encoder positions as desired.

Note: Software Limits do not take effect until the motor is homed.

Note: When Software Limits are activated, the motor will not execute any move that would violate the Software Limit settings.

✓ Enable Software Limits Position Limit 1 (onts) 0 Position Limit 2 (onts) 250000 Note: Your position after homing (after the offset move) will be = 0.	Software Position Limit Setu	o	{d
Position Limit 1 (cnts) 0 Position Limit 2 (cnts) 250000 Note: Your position after homing (after the offset move) will be = 0. 0	Enable Software Limits		
Position Limit 2 (cnts) 250000 Note: Your position after homing (after the offset move) will be = 0. 250000	Position Limit 1 (cnts)	0	
Note: Your position after homing (after the offset move) will be = 0.	Position Limit 2 (cnts)	250000	
	Note: Your position after homing move) will be = 0.	(after the offse	et

Software Limit Setup

Auto-Tune

Select this menu item to begin an Auto-Tuning session. The software is designed to walk you through the Auto-Tune process in a safe, step-by-step manner.

Important: Avoid personal injuries, crashes and machine damage. Carefully read and follow all instructions presented during the Auto-Tune process.

Fine Tuning

This menu item provides a convenient way to "touch up" tuning performance. Turn on the control by checking *Apply Fine Tuning*. Move the slider left for quieter performance, move it right for increased dynamic stiffness. Uncheck to turn it off.

🔑 Fine Tuning	×
While running, ClearPath can be manuall fine-tuned a moderate amount to suit you preference for audible noise versus shaft stiffness (disturbance rejection).	ý
Adjust the slider to make fine adjustments to the tuning.	5
Apply Fine Tuning Fine Tuning	
Quietness Stiffness	

Fine Tuning Setup

Operating Mode

This dialog lets you choose (from three available options) how you will command motion, whether it's through **software motion commands** (more common), or by using an external **step and direction** pulse source, or by using an external **quadrature A/B** pulse source.

C Step & Direc	ction Pulse Input A/B Pulse Input
Pulse Input Se	ettings
Pulses / rev	6400 🔽
Direction (Inpu	ut A) Polarity
CCVV (+) v	vhen Input A is off
C CVV (-) wh	en Input A is off
For more abou	it exercting modes, click

Operating Mode Dialog

Software Command

Select *Software Command* if you intend to command motor motion using only your application software and motion functions in the Teknic sFoundation library. This is the default setting and most common operating mode used with SC family motors.

Step and Direction Pulse Input

Select *Step and Direction* if you plan to use an external step and direction pulse source (PLC, microcontroller, etc.), and you intend to build a machine application and use other functions in the sFoundation motion library.

Quadrature A/B Pulse Input

Select *Quadrature A/B Pulse Input* if you have an external quadrature A/B pulse source (PLC, microcontroller, etc.) and you intend to build a machine application and use other functions in the sFoundation motion library.

Units

Use this menu item to tell ClearView which units to display for velocity and acceleration. Velocity and acceleration can expresses in terms of encoder counts or RPM. Distances are always displayed in encoder counts.

Setup Action	Details Ac	ess [Full] Expe	ert About	
Input Actions		-		-Jog Motion-
Torque Limitin	g	Mayo T		200.0
Homing Setup	•••	MOVe •		
Software Limi	t Setup	ance (cnts)		50,000
Auto-tune				En 1
Fine Tuning		pcity (RPM)		
Operating Mo	de		[]	In the second time
Units	•	Counts; cou	ints/s; coun	ts/s^2
10	0 D	🗸 Counts; RPN	M; RPM/s	R
% of max)				<u> </u>

Units Setup

ACTION MENU

Action Details Acces	ss [Full] Expert Al
Homing Actions	
E-Stop All (Esc)	F12
Clear E-Stop	Shift+F12
Clear All Exceptions	Shift+Ctrl+F12
Enable All	Ctrl+E
Disable All	Ctrl+D
Brake 0 (GPO 0)	+
Brake 1 (GPO 1)	•
Reset Node	Ctrl+R
Reset All Nodes	Ctrl+A

Action Menu

Homing Actions

This menu item provides access to several homing controls, parameters, and homing status indicators. Use these controls to simulate, test, and refine your homing routine without writing code.



Homing Actions

E-Stop All (Esc or F12)

Issues an E-stop (node stop) to all ClearPath-SC motors on the port.

Clears E-stop and returns motors to previous operating states.

Clear All Exceptions (Shift+Ctrl+F12)

Clears exception state and messages. Note: The exception condition may recur if the underlying cause of the exception still exists.

Enable All

Caution: selecting this control will immediately energize all motors on the port. Always treat an enabled motor as if it can move at any moment.

Disable All

Disables all motors on the port.

Brake 0 and Brake 1

Opens a submenu that lets you manually or automatically control the state of a 24V inline brake (or other compatible device).

Action	Details Acces	ss (Full)	About	
Homi	ng Actions			
E-Sto Clear	op All (Esc) r E-Stop	F12 Shift+F	12	
Clear	All Exceptions	Shift+C	trl+F12	
Enab	le All	Ctrl+E		
Disab	ble All	Ctrl+D		
Brake	e 0 (GPO 0)		Þ	Allow Motion (GPO on)
Brake	e 1 (GPO 1)		•	Prevent Motion (GPO off)
Rese	t Node	Ctrl+R		✓ Automatic Brake Control
Rese	t All Nodes	Ctrl+A		↓ ↓
1 t (Allow Motion (Turns on the ou the brake circui (allow motion). Prevent Motio	GPO on itput.Wh t.This we External n (GPO o) nen selecter ould cause power req off)	d, current is allowed to flow in a power-on type brake to release uired.
- - 	Turns the outpu brake circuit. Th (disallow motio	it off. Wh is would n).	nen selecter I cause a po	d, current flow is inhibited in the ower-on type brake to clamp
	Automatic Bra Automatically t enabled, and tu motor is disable	ke Cont urns the rns the c ed.	rol output on output off ((allows motion) when motor is prevents motion) when the

Brake Actions

Reset Node (Ctrl+r)

Resets the currently selected motor.

Reset All Nodes (Ctrl+a)

Resets all motors on the port.

DETAILS MENU

The Details Menu provides access to setup dialogs for the ClearPath-SC features listed below:

- Tracking error limit
- Move status indicators
- Input filtering
- Deceleration rate for E-stops
- Vector Regen Shunt (VRS)
- Actions upon disable
- Power and temperature settings

Detail Access [Full] About Tracking Error Limit... Move Status Indicators... Input A, B Filtering... E-stop Deceleration Rate... Vector Regen Shunt (VRS)... Actions upon Disable... Power and Temperature...

Please read the dialog boxes below to learn more about each feature and its settings.

Tracking Error Limit Setup

P Tracking Error Limit Set	×
In positioning modes, ClearPath continuously monitor how closely it's tracking the desired position (both dur and after moves). If the tracking error exceeds the set limit, ClearPath assumes that there is an error conditi (e.g., mechanical binding), and shuts down to protect motor and mechanics. The minimum value is 0.25 revolutions (or the equival number of counts). Type zero to turn off this safety feat (not recommended).	rs ing on the ent ure
Settings 800 Tracking Error Limit (cnts)	
OK Cance	



🔑 Input A & i	Filtering Set	up	2	K
These settin after it sees a before it con:	gs specify how an input cross siders the inpu	/ long ClearP its logic threa It to have cha	ath will wait shhold nged.	
Use low valu connected, b milliseconds connected in	es when solid ut use higher) when mecha order to "debo	state devices values (tens anical switche ounce" the sv	s are of es are vitches.	
Settings 81	Input A Filter	Time Consta	int (msec)	
81	Input B Filter	Time Consta	ant (msec)	
		ОК	Cancel	

69

Move Status Indicators Setup



E-Stop Deceleration Rate Setup





Actions Upon Disable

Delay	
Delay Disable for 200 m	nsec after commanded
	line to estude)
(Usually done to allow a brake to	time to actuate.)
Action Upon Disable	
While the motor is spinning, if Cle	earPath's Enable Request bit is set
to False, or bus power is lost, Cl	learPath can either:
1) decelerate at the currently set	t rate and then disable.
2) disable first and stop the spin	ning by using the dynamic brake
feature, or	
simply coast to a stop.	
more quickly upon motor disable, deceleration value will often stop	, use dynamic braking. But, a high
braking. Coasting will generally t	ake the longest to stop.
braking. Coasting will generally t	ake the longest to stop.
braking. Coasting will generally t Stopping Method C Dynamic Brake	ake the longest to stop.
braking. Coasting will generally to Stopping Method O Dynamic Brake O Decelerate to Stop	ake the longest to stop.
braking. Coasting will generally to Stopping Method Dynamic Brake C Decelerate to Stop Ramp to a stop at	ake the longest to stop.
braking. Coasting will generally to Stopping Method O Dynamic Brake Decelerate to Stop Ramp to a stop at 40 C Coast to Stop	ake the longest to stop.
braking. Coasting will generally to Stopping Method O Dynamic Brake Decelerate to Stop Ramp to a stop at 40 C Coast to Stop	ake the longest to stop.
braking. Coasting will generally to Stopping Method Dynamic Brake Decelerate to Stop Ramp to a stop at 40 Coast to Stop	ake the longest to stop.
braking. Coasting will generally to Stopping Method © Dynamic Brake © Decelerate to Stop Ramp to a stop at 40 © Coast to Stop	ake the longest to stop.
braking. Coasting will generally to Stopping Method © Dynamic Brake © Decelerate to Stop Ramp to a stop at 40 © Coast to Stop	ake the longest to stop.

Power and Temperature

Status	Power Exception	Exception Type
۲	Bus went below the minimum operating bus voltage	Shutdown O Warning
۲	Bus Voltage Overload	Shutdown only
- Minimu 0.00	m Operating Bus Voltage Minimum operating bus volta	ge (VDC)
- Drive Te	mperature (°C)	
ACCESS MENU

A second computer (or a second port on the same computer) can be connected to your ClearPath-SC via the rear Diagnostic Port. The **Access Menu** lets you specify which of the ports has full control of the motor (only one can).

There are three Access modes. Please see the next section, "Using the Diagnostic Channel", for details on

ile Edit	Setup	Action	Details	Access [Monitor] Expe	ert About		
			ve Gen	✓ Monitor Mode / Appli	cation Channel in I	Full Access Mode	
Disat	le Motor			Tune Mode / Applicat	ion Channel in Ful	Access Mode	
		Ba	ick and	Full Access Mode / A	oplication Channel	in Monitor Mode	

Access Menu

USING THE DIAGNOSTIC CHANNEL

This section describes how to access and use the Diagnostic Channel of your ClearPath-SC motor.

The Diagnostic Channel is accessed via the USB-IR Port located on the back of your motor. It is another way to communicate with your ClearPath motor.

A main benefit of the Diagnostic Channel is that it allows you to run your machine software on the "main" channel (aka, the Application Channel) while simultaneously monitoring performance on the Diagnostic Channel.

TERMS USED IN THIS SECTION

Application Channel. This is the primary communication channel between the Application Computer and ClearPath-SC motor(s). See blue data path in figure below.

Application Computer. This is the PC that runs the machine application software (written by the user).

Diagnostic Channel. This is a secondary data channel that sends data between the ClearPath-SC and either a different port on the Application Computer or a separate PC altogether. The Diagnostic Channel is accessed via the **USB-IR Port** on the back of the motor.

Note: The ClearView software *and* your machine application cannot run on the same channel simultaneously. You can however run your machine application software on the Application Channel and simultaneously run ClearView on the Diagnostic Channel. We'll discuss how to do that later in this section.



Application and Diagnostic Channels are separate communication paths

CONNECTING TO THE DIAGNOSTIC CHANNEL

This example is based on a system with one SC4-HUB that has two ClearPath-SC motors connected.

1. Start with a functional ClearPath system that is communicating with ClearView on the Application Channel (ClearView should identify your motors as shown below).



ClearView's Motor List

2. Connect a USB cable (Type A-C) to the USB-IR Converter and magnetically attach to the motor's USB-IR Port. Then plug the other side into your PC.



3. In ClearView select File>Preferences. An Application Settings window will pop up. The "First" field should show the Application Channel's COM port setting. It is COM 28 in this example.

Application 9	5ettings				×
SC-Hub COM p First:	ort(s): Teknic ClearPath 4-axis S No Port>	SC Hub (COM28)	• •	Event Sounds Enabled: Image: Constraint of the second s	
Third:	:No Port>		- -	Online/Offline Change	

Application Settings window

4. Select the "Second" drop down COM port list. Select Teknic ClearPath System (COMx) and click Done.

SC-Hub COI	/ port(s):	Event Sounds Enabled:
First:	Teknic ClearPath 4-axis SC Hub (COM28)	Torque/Force Saturation
		Voltage Saturation
		() Limit Switch Struck
Second:	<no port=""></no>	Shutdown Occurs
	<no port=""></no>	(1) I Online/Offline Change
Third	Teknic ClearPath System (COM10) Teknic ClearPath 4-aXS SC Hub (COM28)	

Select the Diagnostic COM port as shown

5. The Motor List in ClearView should change to reflect the addition of a motor communicating on the Diagnostic Channel (circled in red below).



Motor "00" now also shows up as "16" on the Diagnostic Channel (COM 10)

Application Channel vs. Diagnostic Channel

Your ClearPath motor typically communicates with your control PC over the Application Channel. Communication signals on the Application Channel pass through the motor's 8-pin connector, to the SC4-HUB, and finally to the application computer through a USB or serial port. In many scenarios, a second communication channel can be helpful. We refer to this as the **Diagnostic Channel**. Communication signals on the Diagnostic Channel pass through the USB-IR Port on the back of your motor.

CHANGING DIAGNOSTIC CHANNEL ACCESS MODES

1. Select the motor of interest from the Motor List (It should appear under the "Rear USB: ONLINE" heading in the UI.



2. Set the access level from the Access menu in ClearView. Users primarily use *Monitor Mode* or *Tune Mode*. Note: Access modes are explained below.

Actio	n Details	Access [Monitor]	About			
1.5	Move Ger	🗸 Monitor Mode /	Application Ch	annel in Ful	Access Mode	L
or		Tune Mode A	pplication Chan	nel in Full A	ccess Mode	
	Back and	Full Access Mo	de / Application	Channel in	Monitor Mode	1
ons	6.400	Distance (onts)		5,000	Acceleration (F	PM/s)
	6,400	Distance (cnts)		5,000	Acceleration (F	.PM/s)

ACCESS MODES EXPLAINED

Monitor Mode

ClearView allows the Diagnostic Channel to access the Soft Scope. ClearView restricts Diagnostic Channel access to most other settings and parameters (restricted items will be grayed out in the UI). The Application Channel has "full access" in this mode.

Tune Mode

ClearView allows the Diagnostic Channel to access the Soft Scope and most of the tuning gains, RAS, and g-Stop settings, tracking error limit, and fine tuning controls. The Application Channel has "full access" in this mode.

Full Access Mode

The Diagnostic Channel has full control of the motor, including access to all normally available settings and parameters. *The Application Channel is forced into "Monitor Mode" in this case*.

TROUBLESHOOTING DIAGNOSTIC CHANNEL CONNECTIONS

If your motors stop communicating with ClearView on one or both channels, or if you get baud rate errors when connecting or reconnecting to the Diagnostic Port, follow these steps:

- 1. On the SC4-HUB: Remove the 24V power and the USB connector. Wait 10 seconds.
- 2. Reconnect 24V power and the USB connector.
- 3. If you still have problems, close and restart ClearView.
- 4. If the problem persists, Click File>Preferences and manually select the ports from the drop down list. Then click "Done". You may have to restart ClearView as well.

Pick the "4-axis SC Hub" to be the First COM port	
Pick the "ClearPath Sys to be the Second COM p	tem" port
Application Settings	×
SC-Hub COM port(s); First: Teknic ClearPath 4-axis SC Hub (20M28) Second: Teknic ClearPath System (COM11)	Event Sounds Enabled: Image: Torque/Force Saturation Image: To
Third: <no port=""></no>]

Manually selecting COM ports

SOFTWARE LIBRARY AND SDK OVERVIEW

INTRODUCTION TO THE SFOUNDATION LIBRARY

The ClearPath-SC software foundation, or "sFoundation", is an objectoriented, motion control class library. The sFoundation has versions for C++ and .NET development. This library includes a large number of functions used to interface with, and control your ClearPath-SC integrated servo motor.

The sFoundation also includes a detailed software development kit (SDK) with all the files you'll need to begin coding immediately. In addition, the SDK includes several example projects and a detailed class reference help document.

WHAT'S COVERED IN THIS SECTION

This section provides a brief overview of the topics listed below. Check out the SDK for the complete programming reference, example programs, header and library files and more.

- sFoundation class hierarchy
- Node level functions
- Port level functions
- System level functions
- Software Development Kit (SDK)

Where do I find on my PC?	the s	Found	ation SI	DK
64-bit systems [DRIVE]:\Program	Files (x8	6)\Teknid	c\ClearVie	w\sdk\
32-bit systems [DRIVE]:\Program	Files\Tek	knic\Clea	rView∖sdk	١

sFoundation Class Hierarchy

The sFoundation libraries are organized into a logical hierarchy (see diagram next page) to help software developers understand class relationships and find relevant functions quickly.

The sFoundation comprises three main levels: a Node level, Port level, and System level. A node is just a ClearPath-SC motor. Most of your application software will interface with Node level objects.

You can think of the sFoundation structure as a hierarchy wherein an instance of a System class object "owns" all of the instances of the Port

class objects (objects which interface with USB or serial ports). Port class objects, in turn, "own" all of the instances of the Node class objects.

You would use **Node class** objects to create and execute positional moves, and to query the node's real-time status (Is the motor enabled? Is the move done?).

Port class objects let you manage individual ports and the collection of all nodes on a given port. Port class objects also provide access to Port level features such as group shutdowns.

Finally, a **System class** defines the manager object used to implement system level functions, things like defining and configuring the USB or serial ports in your system, accessing system timestamps, setting up thread safe delays, and providing a safe thread-locking mechanism.



sFoundation Class Hierarchy

evel System Object

INODE (NODE LEVEL CLASSES)

The INode class is used to interface with a node in an application (remember, each node is just a motor). Node level functions and structures are defined separately for each node in a system, so your application will have one instance of each of these structures for each node (motor) in your system.

This class defines a "super" Node whose framework exposes the Node level features available to your application by a series of public attribute references. You can think of each instance of the INode class as "owning" all Node level classes linked to the same node.

FEATURES/ACTIONS

- Issue Enable requests to motors
- Assign units for torque, velocity, and acceleration
- Provides a simple and safe mutex mechanism
- Read Node level inputs
- Provide access to all other Node level features

OTHER NODE LEVEL CLASSES

IMotion

This class is used to set up, initiate, and cancel motion on an individual node. This class contains functions to:

- Start moves (positional, velocity)
- Query the MoveDone status (to determine whether a move has completed)
- Query the Ready status (to determine whether a node is ready to initiate a move)
- Set/get the velocity limit for moves
- Set/get the acceleration limit for moves
- Query instantaneous commanded and measured position, velocity, and torque
- Provide access to homing and advanced motion features

IMotionAdv

This class object allows setup and initiation of advanced motion features (available only in advanced models) including:

- Head/tail moves
- Asymmetric moves
- Triggered moves
- A after start/ B before end events

IInfo

This class object provides access to node information including:

- Serial number
- Node type
- Firmware version
- User defined node specific information

IStatus

This class object accesses and manages the node status information in status/alert registers. These registers include information such as:

- In Range status
- Input A/B
- Ready status
- Shutdown state
- In Motion status

IStatusAdv

This class accesses and manages the advanced node status information. It provides access to position capture registers (available on advanced models only).

IHoming

This class object gives you hooks into Teknic's homing engine so you can initiate, and check the status of a homing move.

Note: The IHoming class does not configure homing parameters (homing direction, homing speed, etc.). Homing parameters are set quickly and easily right in the ClearView software UI.

ILimits

This class accesses the global torque limit and positional tracking error limit.

ISetup

This class object accesses and manages node setup features such as loading and saving motor configuration files to and from nodes.

IPORT (PORT LEVEL CLASSES)

The IPort class is used to interface with a port on your computer which, in turn, interfaces to a series of nodes. This class defines a "super" Port whose framework exposes the Port Level features available for your application by a series of public attribute references. You can think of the IPort class as "owning" all other port level classes. Port Level functions and structures are defined separately for each port in a system.

FEATURES/ACTIONS

- Request node counts
- Restart nodes on a port network
- Determine the port network's operational state

- Create command trace files logging the history of the last 4096 commands sent through this port
- Issue high priority stop commands to every node on the port
- Provides access to all other Port level classes

OTHER PORT LEVEL CLASSES

IGrpShutdown

Supports control of the group shutdown feature (which allows an electrical connection on the SC4-HUB board or a change in a node's status to initiate a Group Shutdown).

IBrakeControl

Supports control of the brake control outputs on the SC4-HUB board.

Note: If multiple SC4-HUB boards are chained together on a single port, only the first SC4-HUB board's brake outputs will be controllable.

IPortAdv

Supports control of advanced features such as **Group Triggering** and **attention handling** (available on advanced models only).

SYSMANAGER (SYSTEM LEVEL CLASS)

Sometimes called the "root object" for the sFoundation, this is the main application class used to interface with Teknic nodes attached to serial and/or USB ports. Its purpose is to coordinate actions among the various ports, and, to some extent, within the node environment.

COMMON FEATURES

- Port specification function
- Open and close ports, detect any attached nodes
- Access network maintenance features, such as restarting nodes, or re-enumerating the nodes on the port
- Delay function (to suspend thread execution)
- Includes a thread-locking class

SOFTWARE DEVELOPMENT KIT (SDK)

The sFoundation class libraries come with a detailed software development kit (SDK) to help make your software development as straightforward and efficient as possible.

The SDK includes all of the files a developer will need to begin coding, including:

- Header files
- Library .dll
- Class reference help file
- Fully functional example projects, available in both C++ and C#

Tip: Before beginning software development, you may want to copy the complete SDK folder into a different working directory on your computer and leave an unmodified copy of the SDK in the default installation location.

WHERE IS THE SDK LOCATED?

The SDK files are copied to your local machine as part of the ClearView installation process, and can be found in one the following directories:

[YOUR_DRIVE]:\Program Files (x86)\Teknic\ClearView\sdk\

or

[YOUR_DRIVE]:\Program Files\Teknic\ClearView\sdk\

APPENDIX A: MOTOR LED BLINK CODES

Note: The motor LED periodically blinks off to indicate active communication between the motor and the host PC. This communication blinking takes place concurrently with the LED behavior defined in the table below. See examples below for clarification.

Example 1: A motor that is disabled will exhibit a solid green LED, but the LED will periodically blink off and back on during communication with the host PC.

Example 2: An enabled motor will exhibit a rapid green flicker, but the flicker pattern will be interrupted periodically during communication with the host PC. (It will look like a rapid flicker mixed with a slow blink.)

LED Behavior	CPSC State	Description
Green Flicker	Enabled	Operation normal. CAUTION: Motor windings are energized. Motor can move at any time.
Solid Green	Disabled	Operation normal. Motor windings are de- energized.
Yellow Blink	Shutdown	Query drive through application code for exception information, or connect to motor via Diagnostic Port with secondary laptop (running ClearView).
Red Blink	Fatal error	Motor hardware failure possible. Request RMA if condition persists.
Off	No or low DC bus power	Apply DC bus power to motor. Verify power supply meets system power requirements.

APPENDIX B: MECHANICAL REFERENCE

DIMENSIONED DRAWINGS (LINKS)

Motors

NEMA 23 Frame ClearPath-SC Motor (IP66K/67) NEMA 34 Frame ClearPath Motor (IP66K/67)

BOARDS

POWER4-HUB-S POWER4-STRIP-S SC4-HUB

ACCESSORIES

<u>CPMS-USB-IR</u> <u>CPM-COVER-USB-5P</u>

MOTOR MOUNTING: THERMAL CONSIDERATIONS

- Do not mount ClearPath-SC over a heat source such as a power supply, spindle drive, etc.
- Do not mount ClearPath-SC in an unventilated enclosure.
- Do allow for at least 1" of space around each ClearPath-SC.
- ClearPath-SC can be fitted with an external accessory fan if desired.
- ClearPath-SC will perform a protective shutdown when its internal temperature sensor threshold is exceeded.

Tip: Teknic recommends mounting the motor such that the USB-IR Port and status LEDs are visible and accessible when the motor is mounted to the machine.

CONNECTING CLEARPATH-SC TO A MECHANICAL SYSTEM

It's obvious that a ClearPath-SC motor must be connected to a mechanical system to do any useful work. It's *not* always obvious how to connect the motor to the machine mechanics for optimal performance.

Problems arise when a connecting element (such as a coupling) slips, exhibits excessive backlash, or can not accommodate typical shaft-to-shaft misalignments. Ultimately, the choice of shaft interface or coupling depends on the application, be it a high speed, precision positioning stage or a low speed conveyor.

The shaft interface (coupling, pulley, pinion, etc.) must be securely clamped to the shaft such that it cannot loosen over time. This primary mechanical interface is critical in achieving and maintaining the best possible performance from a servo motion system.

MOTOR CONNECTION: GENERAL TIPS AND GUIDELINES

• Align with care. When connecting two shafts—such as a motor shaft to a ball screw shaft—the rotating centers of each side must be carefully aligned in both the angular and offset sense (including margin for thermal growth) to achieve smooth motion transmission and long motor/bearing life.



Some couplings are more forgiving of misalignment than others, but in general, misalignment will cause undesired vibration/noise, shortened bearing life, and even broken motor shafts.

- Use lightweight components. Aluminum couplings, pinions, and pulleys add significantly less inertia to the motion system than steel parts of the same size. In most applications, lower inertia is preferable because it allows the motor (and attached mechanics) to accelerate harder and move and settle faster.
- Avoid using set screws. Coupling devices with set screws are prone to failure and often become the weak link when joining a motor to a load. Set screws deform the metal around the screw's point of contact, often resulting in a raised bur on the shaft that can make it hard to remove and replace the coupling element. Set screws also tend to slip and score the shaft over time.
- **Tip:** Couplings, pulleys and pinions with circumferential clamping mechanisms tend not to damage motor shaft, hold better, and are easier to replace than those that use set screws.

- **Clamp close to the motor.** For maximum performance, secure pulleys and pinions as close to the motor face as practical. This effectively reduces the lever arm (and associated bearing load) for applications with a side load.
- **Don't over tighten belts.** Always read the belt manufacturer's guidelines for proper belt tension, but never exceed the ClearPath-SC specification for maximum side load. Overly tight belts put undue stress on the motor shaft and bearing systems that can result in premature bearing and shaft failure.
- Avoid using shaft keys when possible. Although ClearPath-SC includes a keyway feature on the shaft, Teknic does not generally recommend the use of keys. Keys tend to cause run-out and backlash errors, particularly in bi-directional, precision positioning motion applications.
- **Note:** Keys *should be* considered for use in applications where coupling slip could result in a dangerous or hazardous condition. Also, key use may be appropriate for unidirectional applications (where the motor always spins in the same direction) as these applications are less prone to key-related lash problems.
- Avoid direct loads. In general, ClearPath-SC motors are not designed for connection to high inertia direct loads (e.g. direct connection to a large diameter, heavy grinding wheel). However, direct connection may make sense if the load is of low-mass and balanced, as with small mirrors for laser applications.

NOTES ON COUPLING SELECTION.

A complete coverage of the topic *Coupling Selection for Servo Applications* is beyond the scope of this document, but many articles and resources can be found on the web for those interested in learning more. Because there are so many different coupling styles and applications, selecting the "right" coupling for a particular application can be challenging.

General Guidelines for Coupling Selection

Teknic has a few guiding principles when it comes to coupling selection for servo applications. Keep in mind that these are rules of thumb and may not apply to every application. In general:

- **Don't** undersize the coupling. Understand how much torque your application requires and stay within the coupling manufacturers specifications. Always leave reasonable engineering margin.
- **Don't** use set screw type couplings. They damage the motor shaft and tend to be less reliable over time than clamp style couplings.
- **Do** use clamp style couplings. These clamp around the circumference of the shaft at one or two points without deforming the shaft surface.
- **Don't** use rigid couplings—they are notoriously intolerant of misalignments.
- **Don't** use beam style (helical) couplings if vibration damping or torsional stiffness is critical to your application. Beam couplings tend to resonate/whine at higher speeds.
- **Don't** use any coupling that requires you to drill into, deform, or "pin" the motor shaft.

Coupling Recommendation

Teknic often recommends **zero-backlash curved jaw couplings** (commonly referred to as "spider couplings") as a good choice for many servo applications. These couplings are moderately priced and widely available from well established manufacturers such as Ruland.



Curved Jaw (Spider) Coupling

Bellows Coupling

Couplings for servo applications

Note: Curved jaw couplings (also known as spider couplings) are a good choice for many applications, but cannot tolerate a great deal of misalignment or axial motion. Also, never exceed the manufacturer's rating for "maximum torque with zero backlash" when using jaw couplings.

Bellows couplings are also excellent for high precision positioning applications. Bellows couplings allow for more misalignment than jaw couplings but are generally more expensive.

Both curved jaw and bellows coupling offer excellent positioning accuracy, high speed performance, and vibration damping when installed and operated within the manufacturer's specifications and guidelines.

Coupling Information on the Web

Ruland's website has a good collection of technical information on coupling types and coupling selection for servo systems. See links below.

https://www.ruland.com/technical-resources/technical-articles

https://www.ruland.com/technical-resources/technical-articles/5reasons-to-consider-using-jaw-couplings

INSTALLING PULLEYS AND PINIONS

PULLEY AND PINION MOUNTING

- Always follow the manufacturers mounting guidelines.
- Mount pulleys and pinions as close to the motor face as possible while still following the manufacturer's installation guidelines.
- Never drill through, "pin", or deform the motor shaft when mounting a pulley or pinion.

Application Tip: To prevent loosening/slip, some users bond their pulleys and pinions to the motor shaft with a high strength adhesive such as Loctite #638. While this is very effective in preventing pulley slip, it can be difficult to undo once the adhesive has cured.

End-of-travel stops are typically installed to prevent the moving element of a linear axis from flying off the machine in the event of a use or control error. There are a few common types of end stop to consider, but the final choice depends on the application objectives and requirements.

HARD BLOCKS

This is usually a solid block of steel, aluminum, or hard plastic secured at one or both ends of travel and positioned in such a way as to make even, repeatable contact with a hard surface on the moving element. Hard blocks are very effective at arresting motion, but can result in mechanical damage when struck at high speeds.

In several modes, ClearPath-SC must home to a hard stop to establish a home reference position before functional positioning can begin.

ELASTOMERIC (RUBBER) STOPS

High durometer rubber stops (hard rubber) can also be used with applications that use HardStop Homing. This type of end stop offers a higher level of shock absorption and axis protection than hard blocks. Spongy, low durometer rubber stops are not recommended in most cases. They offer little benefit over a hard end stop during an axis crash.

PNEUMATIC (DASHPOTS)

Pneumatic hard stops (dashpots) offer excellent shock absorption performance but are considerably more expensive than hard blocks. Examples of specialized dashpots include the hydraulic cylinder in an automobile shock absorber as well as many automatic door closers.

END STOPS AND HARD STOP HOMING

End stops from medium durometer rubber to steel can be used successfully with Hard Stop Homing. When selecting end stops for a Hard Stop Homing application consider the following:

- Axes with low friction that are easily back driven can tolerate "softer" rubber end stops and still achieve good homing performance.
- Higher friction applications and those that cannot be back driven will generally require harder end stop material to achieve best Hard Stop Homing performance.
- Be prepared to test and experiment with different end block materials to ensure proper homing operation with your mechanical system.

FAN MOUNTING AND COOLING.

ClearPath-SC motors have unthreaded mounting bosses on the rear casting to accommodate standard size computer fans (60mm for NEMA 34 motors, and 40mm for NEMA23 size motors). See the diagram below for mounting dimensions, hardware and fan sizes. Teknic does not sell accessory fans, but these types of fans are readily available through Digikey, Mouser, Amazon, etc.

Note: As a self-protective measure, ClearPath-SC motors will shut down when the rear enclosure reaches 80° C (176° F). After a thermal shutdown occurs, the motor must cool sufficiently before it will operate again.

Reminder: If you install a fan, you'll have to power it via an external power source. Most computer fans require 12VDC or 24VDC.



APPENDIX C: CONNECTOR AND CABLE REFERENCE

This section contains part numbers for ClearPath-SC mating connectors, terminals, and hand tools and links to ClearPath-SC cable drawings.

MATING CONNECTORS



Parts listed in table manufactured by Molex Inc. Visit www.molex.com for complete specifications and application information.

Pof	Desc	Mating Connector PN	Terminal PN	Terminal Desc	Crimp Tool	Extraction	Wire Gauge ¹
A	Molex Sabre, Receptacle, 2 circuits	44441-1002 (natural, UL 94V-2) 44441-2002 (black, UL 94V-0)	43375-0001	Female crimp terminal, tin plate, 14-16 AWG	63811-7200 (14-16 AWG)	63813-2700	16 AWG
В	Molex MiniFit-Jr, Receptacle, 2 circuits	39-01-2020 (natural, UL 94V-2) 39-01-3025 (black, UL 94V-2) 39-01-3028 (natural, UL 94V-0) 39-03-9022 (black, UL 94V-0)	39-00-0059 (reel) 39-00-0060 (loose)	Female crimp terminal, tin plate, 18-24 AWG	63819-0901 (18-24 AWG)	11-03-0044	20 AWG
<u>^</u>	Molex MiniFit-Jr,	39-01-2040 (natural, UL 94V-2) 39-01-3045 (black, UL 94V-2)	39-00-0077 (reel) 39-00-0078 (loose)	Female crimp terminal, tin plate, 16 AWG	200218-2200 (16 AWG)	11 00 0011	16 AWG (Pins 2,3)
С	Receptacie, 4 circuits	39-01-2045 (natural, UL 94V-0) 39-03-9042 (black, UL 94V-0)	39-00-0046 (reel) 39-00-0047 (loose)	Female crimp terminal, tin plate, 22-28 AWG	63819-1000 (22-28 AWG)	11-03-0044	22 AWG (Pins 1,4)
D	Molex MiniFit-Jr, Receptacle, 8 circuits	39-01-2080 (natural, UL 94V-2) 39-01-3085 (black, UL 94V-2) 39-01-2085 (natural, UL 94V-0) 39-03-9082 (black, UL 94V-0)	39-00-0046 (reel) 39-00-0047 (loose)	Female crimp terminal, tin plate, 22-28 AWG	63819-1000 (22-28 AWG)	11-03-0044	22 AWG

¹AWG values listed are the actual wire gauges used in Teknic-manufactured cables.

CABLE DRAWINGS AND PINOUTS (LINKS TO TEKNIC.COM)

IMPORTANT: The motor cable connectors must be properly tightened to maintain IP67 (waterproof) rating. Failure to tighten these connectors may result in motor damage due to water ingress.

CPMS-CABLE-PWR-KK660 CPMS-CABLE-PWR-KM120 CPMS-CABLE-CTRL-AA660 CPMS-CABLE-CTRL-AM120

APPENDIX D: SPECIFICATIONS

CLEARPATH-SC MOTOR: COMMON SPECIFICATIONS

Electrical Power Requirements, DC Bus Supply	
Bus Supply Voltage, Typical	24VDC to 75VDC
Bus Supply Voltage, Absolute Min	21.5VDC (as measured at input terminals)
Bus Supply Voltage, Absolute Max	90VDC (as measured at input terminals)
Continuous Bus Current, Typical	1A to 4A (application dependent)
Continuous Bus Current, Maximum	10A
Idle Power usage from Bus	4W (enabled, no torque), 3W (disabled)
Electrical Power Requirements, Logic Power Backup Supply	
Supply Voltage, Typical	12-75 VDC (full range); 12-42 VDC (touch-safe range)
Supply Voltage, Absolute Min	10 VDC (as measured at input terminals)
Supply Voltage, Absolute Max	90 VDC (as measured at input terminals)
Continuous Power, Typical	3W
Continuous Power, Maximum	4W
Electrical I/O	
Control Signal Voltage Range	4.0VDC to 28VDC
Input Current @ 5V	7.5mA (min.)
Input Current @ 28V	12 0mA (min)
Motor Bearing, NFMA34	
Maximum Radial Load, NEMA34	220N (50-lbs), applied 25mm (1 0in) from front bearing
Maximum Thrust Load, NEMA34	44N (10-lbs)
Bearing Life NEMA34	2.4×10^9 to 5.3×10^9 revs (typ_load dependent)
Motor Bearing NEMA23	
Maximum Radial Load NEMA23	110N (25 lbs) applied 25mm (1 0in) from front bearing
Maximum Thrust Load, NEMA23	22N (5 lbs)
Bearing Life NEMA23	3.2×10^{9} to 5.0×10^{9} revs (typ_load dependent)
M12 Connector Torque	0.6Nm - 1.4 Nm
Environmental	0.0000 1.1000
Shock (neak_maximum)	10G (applied no more than twice)
Vibration (PMS_2 Hz-200 Hz)	1.0G or 0.5mm, whichever is less
Maximum External Shaft Deceleration	250 000 rad/s2
Ambient Temperature	-40° C to $\pm 70^{\circ}$ C*
Mavimum Body Temp	100°C
Maximum Doar Cover Temp.	70°C
Humidity	0.100%
Decommonded Optional Ean NEMA22	40mm square 45.25 mm bolt contor >7 CEM
Recommended Optional Fan, NEMA23	40mm square, 45.25 mm bolt center, >7 CFM
Environmental Seeling	outiliti square, 70.71 tiliti buli center, >14 CFM
Environmental Sealing	
	IP00N/IP07
Motor without optional shaft seal	IP53
Compliance	
Regulatory Certifications	UL (pending), CE, RoHS
Electrical Safety	UL508C, EN 61010-1 (pending)
EMI	EN 61326-1 (pending)
Country of Origin	USA
Warranty	3 years

*The RMS torque limit on certain motors is derated for operation in ambient temperatures above +40°C. Contact Teknic for derating assistance.

SC4-HUB SPECIFICATIONS

USB

	USB Standard	USB 2.0 w/hub, USB 1.1 direct
	Power Draw	If 24V is present, 0.4mA max
		If 24V is not present, 150mA max.
	Connector:	USB-B
RS-232 to PC		
	Compatible baud rates:	Up to 230 kBaud
	Connector:	DB-9 female, use DB-9 straight-through cable (male to female) to connect to PC
RS-232 Exten	sion	
NO 202 EXICI	Compatibility:	Intended for direct connection to another SC4-HUB board only
		DB-9 male (can be plugged directly into J1 of another SC4-HUB, or through another
	Connector:	straight-through DB-9 cable)
Global Stop Ir	tuqu	
	Input Type:	Isolated loop
	Specified voltage range:	0-24VDC
	Current draw:	2mA@4.5V, 12mA@24V
	Min. guaranteed on voltage:	3.0VDC
	Max. guaranteed off voltage:	2.0VDC
	Max. input voltage:	26VDC
	Connector:	2-pin MiniFit Ir
		- Far
Brake Outputs	8	
	Output type:	Powered open collector
	Output voltage:	24VDC
	Rated current:	500mA per channel, max.
	Short circuit protected with built-in indu	ictive clamp
	Connectors:	2-pin MiniFit Jr. (x2)
Dower Input		
rower input	Specified voltage range:	20VDC to 30VDC
	Max. input voltage	40VDC
	Current draw:	300mA (+ up to 500mA per brake)
	Connectors:	2-pin MiniFit Ir (x2)
ClearPath Inte	erface	
	Compatibility:	Intended for direct connection to a ClearPath-SC motor only
	Connectors:	8-pin MiniFit Jr. (x4)
Class Dath Inn	ute A and D accethrough	
ClearPain inp	Direct passtbrough of ClearDath inputs	A and P with 24W courtosy newer for sonsors
	Connectors.	4-nin MiniFit Ir (x8)
Dimensions:		
	L x W x H (w/o plate)	5.60" x 3.50" x 0.65"
	L x W x H (with plate)	5.60" x 3.56" x 0.82"
Operating Tor	nnerature: AOC May	
Country of Or	inin. 400 MdX.	
Warranty:	iyiii.	1 year
warranty:		r year

POWER4-HUB-S SPECIFICATIONS

DC Bus Power (Input from DC bus supply)

	Nominal voltage range	24VDC to 75VDC
	Max. input voltage	90VDC
	Max. continuous current	20A
	Peak current (3 seconds)	50A
	Connectors	2-pin Molex Sabre (P1, P2)
Logic Backup	Power (Input from Logic Backup Power Supply)	
	Nominal voltage range (full range)	12VDC to 75VDC
	Nominal voltage range (touch-safe range)	12VDC to 42VDC
	Max. input voltage	90VDC
	Max. continuous current	10A
	Max. peak current	10A
	Connectors	2-pin Molex MiniFit Jr. (P3, P4)
DC Bus Power	(Output to ClearPath motors)	
	Max. motors	4
	Connectors	4-pin Molex MiniFit Jr. (P1, P2, P3, P4)
Dielectric With	stand Voltage	
	Between DC Bus and Backup Power	1,600 VDC
	Between DC Bus and chassis plate	1,600 VDC
	Between Backup Power and chassis plate	1,600 VDC
Environmental		
	Operating temperature**	-40°C to +70°C
	Long term storage temperature	-40°C to +50°C
	Pollution Degree	2
Dimensions		
	L x W x H (w/o baseplate)	3.37" x 2.23" x 0.67"
	L x W x H (with baseplate)	3.62" x 2.35" x 1.03"
Country of Ori	gin	USA
Warranty		1 year

**For operation over 40°C refer to power derating data

POWER4-STRIP-S SPECIFICATIONS

DC Bus Power (Input from DC bus supply)

	Nominal voltage range	24VDC to 75VDC
	Max. input voltage	90VDC
	Max. continuous current	20A
	Peak current (3 seconds)	50A
	Connectors	2-pin Molex Sabre (P1, P2)
DC Bus Pow	er (Output to ClearPath motors)	
	Max. motors	4
	Max. continuous current	10A
	Peak current (3 seconds)	20A
	Connectors	4-pin Molex MiniFit Jr. (P1, P2, P3, P4)
Environmen	tal	
	Operating temperature**	-40°C to +70°C
	Long term storage temperature	-40°C to +50°C
	Pollution Degree	2
Dielectric Wi	ithstand Voltage	
	Between DC Bus and chassis plate	1,600 VDC
Dimensions		
	L x W x H (w/o baseplate)	3.37" x 2.23" x 0.67"
	L x W x H (with baseplate)	3.62" x 2.35" x 1.03"
Country of C	Drigin	USA
Warranty		1 year

**For operation over 40°C refer to power derating curves in this manual

APPENDIX E: GROUNDING AND SHIELDING

PROTECTIVE EARTH (PE) CONNECTION

Compliance Note: ClearPath-SC must be properly connected to the machine's Protective Earth terminal to meet EMC emissions specification EN-61000-6-4, and EMC immunity specification EN-61000-6-2, as well as EMC electrical safety specification EN-61010 (for CE/UL compliance).

Connect ClearPath-SC to your machine's Protective Earth terminal (PE) using one of the following methods.

- If the motor mounting plate is bonded to machine PE (typical), most of the work is already done. Simply secure ClearPath-SC to the mounting plate with conductive fasteners (don't use anodized or coated hardware). Ensure direct, bare metal-to-metal contact between the ClearPath-SC motor face and mounting surface.
- If the motor mounting plate *is not* bonded to machine PE it's still easy to make a good PE connection. Just install a grounding wire from ClearPath-SC's Auxiliary PE Connection Point (located on the motor's rear casting) to a point on the machine that is bonded to machine PE. Use #6-32, thread forming screw, 5/16" length (McMaster-Carr PN 93878A145). Use grounding wire with same AWG number (or heavier) as the ClearPath DC power input wiring.

Note: In scenarios where ClearPath-SC *is not* connected to a PE (Protective Earth) return path—such as during bench testing or maintenance–temporary grounding measures may be necessary to comply with safety requirements.

GROUNDING AND SHIELDING

- Always maintain separation between isolated control ground and power ground.
- Shielded cable is not required for ClearPath-SC control cables.
- If you choose to use shielded control cable, connect the cable's isolated ground at one point at the controller only. Do not hook isolated control ground to the machine frame or chassis at any other location.
- Do not ground ClearPath-SC I/O circuits to the machine frame or chassis.

Note: All ClearPath-SC I/O signals are electrically isolated from ClearPath-SC's DC power input and motor output circuits, as well as from the motor case. This design feature helps to ensure that control signals aren't compromised by induced currents from the motor, power supply, or internal PWM.

POWER RETURNS

- Never use the machine frame or chassis as a power return. Use discrete cable or wires for all power wiring.
- Use only recommended wire gauge (16-18AWG typical) for all ClearPath-SC power wiring. When in doubt, use heavier wire.

APPENDIX F: CIRCUIT SCHEMATICS

All schematics in this section are functionally accurate. Certain advanced circuit elements have been omitted for clarity.



SC4-HUB SCHEMATIC (SIMPLIFIED)

SC4-HUB simplified schematic page 1







SC4-HUB simplified schematic page 2

APPENDIX G: WIRING THE INPUTS

Each ClearPath-SC motor has two available inputs (Input A and B). Inputs are wired to the SC4-HUB and passed to the motor via the ClearPath I/O connector as shown below.

WIRING A MECHANICAL SWITCH TO AN INPUT



A mechanical switch wired to Input B on the SC4-HUB

WIRING A 24V NPN SENSOR TO AN INPUT



An 24V sensor wired to one input on the SC4-HUB board

TEL. (585) 784-7454

APPLICATION EXAMPLE: WIRING AN OPTICAL SENSOR TO AN INPUT

The example below is based on the Omron EE-SX670 optical slot sensor.





Wiring the Omron EE-SX670 24V optical slot sensor to a CP-SC input

APPENDIX H: MOTOR PART NUMBER KEY

Use the chart below to decode your ClearPath-SC part number, or visit <u>Teknic's website</u> and enter your motor part number into the search bar for complete information including specifications, torque-speed curves, and links to drawings and documentation.

	Example Part Number		M - <u>S D H P</u> - <u>3 4 4 1 H</u> - <u>E L N A</u>
		0	
1	Product ID	CPM	ClearPath [®] Motor
2	Family/Model	SDSK	Step & Direction / "Stepper Killer"(2-3x the power of a similarly sized stepper)
		SDHP	Step & Direction / High Power model (8-15x the power of a similarly sized stepper)
		MCVC	Motion Controller / Velocity, Torque, 2 Position Modes
		MCPV	Motion Controller / Position, Velocity, Torque Modes
		SCSK	Software Control / "Stepper Killer"(3x the power of similarly sized steppers)
		SCHP	Software Control / High Power model(8-15x the power of similarly sized steppers)
3	Motor Frame Size	23	NEMA 23 frame
		34	NEMA 34 frame
4	Body Length Approximate, excludes shaft length	1	NEMA 23: 91mm NEMA 34: 84mm
		2	NEMA 23: 110mm NEMA 34: 103mm
		3	NEMA 23: 129mm NEMA 34: 122mm
		4	NEMA 23: 148mm NEMA 34: 141mm
5	Winding/Magnetic Structure	0	
		1	
		2	Indicates specific winding design. See your motor's torque-speed curve for more information.
		5	
		6	
6	Winding Type	Н	Series-Wye (higher torque, lower speed)
		F	Parallel-Wye (in between H and J characteristics)
		J	Parallel-Delta (higher speed, lower torque)
7	Enhanced Options	R	Positioning Resolution = 800 counts per revolution
		<u> </u>	Positioning Resolution = 6400 counts per revolution
8	Shaft Diameter	L	Standard diameter (NEMA 34 = 1/2" dia., NEMA 23 = 3/8" dia.)
		Q	1/4" shatt diameter (available only on NEMA 23 models with body length 1 or 2)
9	Shaft Seal	N	Standard dust sealing
		S	Extra PTFE infused polyimide seal. Not available on 1/4" shaft models.
10	Feature Set	В	Basic features; see list below.
	(tor SC models only)	Α	Advanced features; see list below.

Basic Features, SC models only

Velocity moves Global torque limit HardStop foldback (homing) Trapezoidal moves Node stops / e-stops Reading and modifying positions RAS™ (jerk limiting) Status registers Warning and alert system Parameter memory Safety shutdowns Soft limits User defined data Automatic brake coil control Group shutdowns

Advanced Features, SC models only (Includes all Basic Features)

RAS™ & g-Stop™ (jerk limiting & vibration suppression) Positive and Negative torque limiting Triggered moves (on input or command, including move groups) Head-tail moves Asymmetric moves A-after-start event generation B-before-end event generation Conditional torque limiting Attention generation Position capture
APPENDIX I: LOGIC POWER SUPPLY SIZING

This section was designed to help users estimate how much power (wattage) to specify when selecting a logic power supply for a ClearPath system.

The worksheet below lists the power rating of ClearPath "logic power" system components. Space is provided for calculation of total estimated power usage for any combination of these components.

	Power				Line Total
Part	Req'd (ea)	х	Qty	=	(Watts)
SC4-HUB (24 VDC supply)	5W	x		=	
POWER4-HUB-S @12-24 VDC	2W	х		=	
POWER4-HUB-S @ >24VDC	3W				
Brake/GPO (optional)	w	х		=	
Input Sensors (optional)	w	х		=	
Other	w	x		=	

Grand Total (Watts)

APPENDIX J: HOW TO MAKE A 24V LOGIC SUPPLY CABLE

All ClearPath-SC systems require a 24VDC supply for the SC4-Hub. The 24 VDC cable must be terminated with a 2-pin Molex connector. This appendix shows a quick, inexpensive way to make a "no-crimp" cable for use with a 24VDC supply.

- 1. Select a 24VDC power supply. A supply with screw terminals is easy to wire. A 1.5 amp supply will generally suffice for smaller systems (4 axes or less), but the *actual minimum current rating depends on the current draw of all devices powered by the supply (sensors, brakes, etc.).*
- 2. Order a Teknic CPM-CABLE-M2P2P-120. This is a 120" (10-ft.), 2-pin Molex to 2-pin Molex cable as shown below.



CPM-CABLE-M2P2P-120

- 3. Cut the cable to the desired length. If you cut it exactly in half, you can make two five foot long cables.
- 4. Strip the outer jacket and conductors on the unterminated end of the cable to create flying leads.
- 5. Connect the flying leads to your 24VDC supply. Insulate any exposed conductors with heat shrinkable tubing, electrical tape or similar.
- 6. **Test DC output polarity before connecting.** Use a DMM to verify proper polarity at the DC output connector. Use the above diagram as a reference.

Teknic, Incorporated 7650 Omnitech Pl Victor, NY 14564

© 2024 TEKNIC INCORPORATED, ALL RIGHTS RESERVED